



OPERATOR'S AND PARTS MANUAL

COLD PLANER - STANDARD FLOW SP300

**FOR
SKID STEER LOADERS**



SERIAL NUMBER: _____

MODEL NUMBER: _____

Manual Number: OM670
Part Number: 75570
Rev. 8

STANLEY Dubuis 17-19, rue Jules Berthanneau-BP 3406 41034 Blois Cedex, France

800-456-7100 | www.paladinattachments.com

503 Gay Street, Delhi, IA 52223, United States of America Copyright ©



TABLE OF CONTENTS

PREFACE	3
SAFETY PRECAUTIONS	
SAFETY STATEMENTS	5
GENERAL SAFETY PRECAUTIONS	5-7
EQUIPMENT SAFETY PRECAUTIONS	8-9
DECALS	
DECAL PLACEMENT	10
DECALS	11-12
PRE-OPERATION	13-14
INSTALLATION	15-16
OPERATING INSTRUCTIONS	
GENERAL OPERATING INSTRUCTIONS	17-18
SPECIAL APPLICATIONS	19-20
Large Area	
Milling Around Manholes	
Deep Cuts	
Milling Taper Cuts	
STORAGE	21
LIFT POINTS	21-22
TIE DOWN POINTS	22
MAINTENANCE AND SERVICE	
LUBRICATION	23
ROUTINE MAINTENANCE	24
PICK REPLACEMENT	25
CHANGING THE DRUM	26
CHANGING THE PLANETARY	26-27
CHANGING THE HYDRAULIC MOTOR	27
CYLINDER SEAL REPLACEMENT	28-29
TROUBLESHOOTING	30-31
SPECIFICATIONS	
BOLT TORQUE SPECIFICATIONS	32
COLD PLANER SPECIFICATIONS	33
LIMITED WARRANTY	35
PARTS	
PLANER ASSEMBLY	36-39
DRUM AND PICK OPTIONS	40-41
WHEEL ASSEMBLY	42-43
HYDRAULIC ASSEMBLIES #100458 & #38749	44-45
HYDRAULIC ASSEMBLIES #19038 & #38748	46-47
PLANETARY ASSEMBLY - AUBURN	48-49
CYLINDER ASSEMBLY #19202	50-51
CYLINDER ASSEMBLY #89520	52-53
CYLINDER ASSEMBLY #89530	54-55
WATER NOZZLE KIT #19216	56-57

**THIS PAGE
IS INTENTIONALLY
BLANK**

PREFACE

GENERAL COMMENTS

Congratulations on the purchase of your new BRADCO product! This product was carefully designed and manufactured to give you many years of dependable service. Only minor maintenance (such as cleaning and lubricating) is required to keep it in top working condition. Be sure to observe all maintenance procedures and safety precautions in this manual and on any safety decals located on the product and on any equipment on which the attachment is mounted.

This manual has been designed to help you do a better, safer job. Read this manual carefully and become familiar with its contents.

WARNING! Never let anyone operate this unit without reading the "Safety Precautions" and "Operating Instructions" sections of this manual.



Always choose hard, level ground to park the vehicle on and set the brake so the unit cannot roll.

Unless noted otherwise, right and left sides are determined from the operator's control position when facing forward.

NOTE: The illustrations and data used in this manual were current (according to the information available to us) at the time of printing, however, we reserve the right to redesign and change the attachment as may be necessary without notification.

BEFORE OPERATION

The primary responsibility for safety with this equipment falls to the operator. Make sure the equipment is operated only by trained individuals that have read and understand this manual. If there is any portion of this manual or function you do not understand, contact your local authorized dealer or the manufacturer to obtain further assistance. Keep this manual available for reference. Provide the manual to any new owners and/or operators.

SAFETY ALERT SYMBOL



This is the "Safety Alert Symbol" used by this industry. This symbol is used to warn of possible injury. Be sure to read all warnings carefully. They are included for your safety and for the safety of others working with you.

SERVICE

Use only manufacturer replacement parts. Substitute parts may not meet the required standards.

Record the model and serial number of your unit on the cover of this manual. The parts department needs this information to insure that you receive the correct parts.

SOUND AND VIBRATION

Sound pressure levels and vibration data for this attachment are influenced by many different parameters: some items are listed below (not inclusive):

- prime mover type, age, condition, with or without cab enclosure and configuration
- operator training, behavior, stress level
- job site organization, working material condition, environment

Based on the uncertainty of the prime mover, operator, and job site, it is not possible to get precise machine and operator sound pressure levels or vibration levels for this attachment.

NOTE: A list of all Paladin Patents can be found at <http://www.paladinattachments.com/patents.asp>.

**THIS PAGE
IS INTENTIONALLY
BLANK**

SAFETY STATEMENTS



THIS SYMBOL BY ITSELF OR WITH A WARNING WORD THROUGHOUT THIS MANUAL IS USED TO CALL YOUR ATTENTION TO INSTRUCTIONS INVOLVING YOUR PERSONAL SAFETY OR THE SAFETY OF OTHERS. FAILURE TO FOLLOW THESE INSTRUCTIONS CAN RESULT IN INJURY OR DEATH.



DANGER

THIS SIGNAL WORD INDICATES A HAZARDOUS SITUATION WHICH, IF NOT AVOIDED, WILL RESULT IN DEATH OR SERIOUS INJURY.



WARNING

THIS SIGNAL WORD INDICATES A HAZARDOUS SITUATION WHICH, IF NOT AVOIDED, COULD RESULT IN DEATH OR SERIOUS INJURY.



CAUTION

THIS SIGNAL WORD INDICATES A HAZARDOUS SITUATION WHICH, IF NOT AVOIDED, COULD RESULT IN MINOR OR MODERATE INJURY.

NOTICE

NOTICE IS USED TO ADDRESS PRACTICES NOT RELATED TO PHYSICAL INJURY.

GENERAL SAFETY PRECAUTIONS

WARNING!



READ MANUAL PRIOR TO INSTALLATION

Improper installation, operation, or maintenance of this equipment could result in serious injury or death. Operators and maintenance personnel should read this manual, as well as all manuals related to this equipment and the prime mover thoroughly before beginning installation, operation, or maintenance. **FOLLOW ALL SAFETY INSTRUCTIONS IN THIS MANUAL AND THE PRIME MOVER'S MANUAL(S).**



READ AND UNDERSTAND ALL SAFETY STATEMENTS

Read all safety decals and safety statements in all manuals prior to operating or working on this equipment. Know and obey all OSHA regulations, local laws, and other professional guidelines for your operation. Know and follow good work practices when assembling, maintaining, repairing, mounting, removing, or operating this equipment.



KNOW YOUR EQUIPMENT

Know your equipment's capabilities, dimensions, and operations before operating. Visually inspect your equipment before you start, and never operate equipment that is not in proper working order with all safety devices intact. Check all hardware to ensure it is tight. Make certain that all locking pins, latches, and connection devices are properly installed and secured. Remove and replace any damaged, fatigued, or excessively worn parts. Make certain all safety decals are in place and are legible. Keep decals clean, and replace them if they become worn or hard to read.

GENERAL SAFETY PRECAUTIONS

WARNING!



PROTECT AGAINST FLYING DEBRIS

Always wear proper safety glasses, goggles, or a face shield when driving pins in or out, or when any operation causes dust, flying debris, or any other hazardous material.

WARNING!



LOWER OR SUPPORT RAISED EQUIPMENT

Do not work under raised booms without supporting them. Do not use support material made of concrete blocks, logs, buckets, barrels, or any other material that could suddenly collapse or shift positions. Make sure support material is solid, not decayed, warped, twisted, or tapered. Lower booms to ground level or on blocks. Lower booms and attachments to the ground before leaving the cab or operator's station.


WARNING!



USE CARE WITH HYDRAULIC FLUID PRESSURE

Hydraulic fluid under pressure can penetrate the skin and cause serious injury or death. Hydraulic leaks under pressure may not be visible. Before connecting or disconnecting hydraulic hoses, read your prime mover's operator's manual for detailed instructions on connecting and disconnecting hydraulic hoses or fittings.

- Keep unprotected body parts, such as face, eyes, and arms as far away as possible from a suspected leak. Flesh injected with hydraulic fluid may develop gangrene or other permanent disabilities.
- If injured by injected fluid, see a doctor at once. If your doctor is not familiar with this type of injury, ask him to research it immediately to determine proper treatment.
- Wear safety glasses, protective clothing, and use a piece of cardboard or wood when searching for hydraulic leaks. **DO NOT USE YOUR HANDS!** **SEE ILLUSTRATION.**



GENERAL SAFETY PRECAUTIONS

WARNING!



DO NOT MODIFY MACHINE OR ATTACHMENTS

Modifications may weaken the integrity of the attachment and may impair the function, safety, life, and performance of the attachment. When making repairs, use only the manufacturer's genuine parts, following authorized instructions. Other parts may be substandard in fit and quality. Never modify any ROPS (Roll Over Protective Structure) or FOPS (Falling Object Protective Structure) equipment or device. Any modifications must be authorized in writing by the manufacturer.

WARNING!



SAFELY MAINTAIN AND REPAIR EQUIPMENT

- Do not wear loose clothing or any accessories that can catch in moving parts. If you have long hair, cover or secure it so that it does not become entangled in the equipment.
- Work on a level surface in a well-lit area.
- Use properly grounded electrical outlets and tools.
- Use the correct tools for the job at hand. Make sure they are in good condition for the task required.
- Wear the protective equipment specified by the tool manufacturer.



SAFELY OPERATE EQUIPMENT

Do not operate equipment until you are completely trained by a qualified operator in how to use the controls, know its capabilities, dimensions, and all safety requirements. See your machine's manual for these instructions.

- Keep all step plates, grab bars, pedals, and controls free of dirt, grease, debris, and oil.
- Never allow anyone to be around the equipment when it is operating.
- Do not allow riders on the attachment or the prime mover.
- Do not operate the equipment from anywhere other than the correct operator's position.
- Never leave equipment unattended with the engine running, or with this attachment in a raised position.
- Do not alter or remove any safety feature from the prime mover or this attachment.
- Know your work site safety rules as well as traffic rules and flow. When in doubt on any safety issue, contact your supervisor or safety coordinator for an explanation.

WARNING!



CALIFORNIA PROPOSITION 65 WARNING

This product may contain a chemical known to the state of California to cause cancer, or birth defects or other reproductive harm. www.P65Warnings.ca.gov

EQUIPMENT SAFETY PRECAUTIONS

WARNING!



KNOW WHERE UTILITIES ARE

Observe overhead electrical and other utility lines. Be sure equipment will clear them. When digging, call your local utilities for location of buried utility lines, gas, water, and sewer, as well as any other hazard you may encounter.

WARNING!



EXPOSURE TO RESPIRABLE CRYSTALLINE SILICA DUST ALONG WITH OTHER HAZARDOUS DUSTS MAY CAUSE SERIOUS OR FATAL RESPIRATORY DISEASE.

This attachment is designed to plane (mill) rock, concrete and asphalt, causing high levels of dust. It is recommended to use dust suppression, dust collection and if necessary personal protective equipment during the operation of the planer or of any attachment that may cause high levels of dust.

WARNING!



REMOVE PAINT BEFORE WELDING OR HEATING

Hazardous fumes/dust can be generated when paint is heated by welding, soldering or using a torch. Do all work outside or in a well ventilated area and dispose of paint and solvent properly. Remove paint before welding or heating.

When sanding or grinding paint, avoid breathing the dust. Wear an approved respirator. If you use solvent or paint stripper, remove stripper with soap and water before welding. Remove solvent or paint stripper containers and other flammable material from area. Allow fumes to disperse at least 15 minutes before welding or heating.

WARNING!



END OF LIFE DISPOSAL

At the completion of the useful life of the unit, drain all fluids and dismantle by separating the different materials (rubber, steel, plastic, etc.). Follow all federal, state and local regulations for recycling and disposal of the fluid and components.



OPERATING THE PLANER

- Block off work area from bystanders, livestock, etc.
- Operate only from the operator's station.
- Reduce speed when driving over rough terrain, on a slope, or turning, to avoid overturning the vehicle.
- An operator must not use drugs or alcohol, which can change his or her alertness or coordination. An operator taking prescription or over-the-counter drugs should seek medical advice on whether or not he or she can safely operate equipment.
- Before exiting the prime mover, lower the attachment to the ground, turn off the prime mover's engine, remove the key and apply the brakes.
- Be sure all doors, guards and shields are in their proper position and securely attached before operating the planer.

EQUIPMENT SAFETY PRECAUTIONS



TRANSPORTING THE PLANER

- Travel only with the attachment in a safe transport position to prevent uncontrolled movement. Drive slowly over rough ground and on slopes.
- When transporting on a trailer: Secure attachment at recommended tie down locations using tie down accessories that are capable of maintaining attachment stability.
- When driving on public roads use safety lights, reflectors, Slow Moving Vehicle signs etc., to prevent accidents. Check local government regulations that may affect you.
- Do not drive close to ditches, excavations, etc., cave in could result.
- Do not smoke when refueling the prime mover. Allow room in the fuel tank for expansion. Wipe up any spilled fuel. Secure cap tightly when done.



MAINTAINING THE PLANER


- Before performing maintenance, lower the attachment to the ground, turn off the engine, remove the key and apply the brakes.
- Never perform any work on the attachment unless you are authorized and qualified to do so. Always read the operator service manual's before any repair is made. After completing maintenance or repair, check for correct functioning of the attachment. If not functioning properly, always tag "DO NOT OPERATE" until all problems are corrected.
- Worn, damaged, or illegible safety decals must be replaced. New safety decals can be ordered from BRADCO.
- Never make hydraulic repairs while the system is under pressure. Serious personal injury or death could result.
- Never work under a raised attachment.

DECALS

DECAL PLACEMENT

GENERAL INFORMATION

The diagram on this page shows the location of the decals used on the Cold Planer. The decals are identified by their part numbers, with reductions of the actual decals located on the following pages. Use this information to order replacements for lost or damaged decals. Be sure to read all decals before operating the attachment. They contain information you need to know for both safety and product longevity.



IMPORTANT: Keep all safety decals clean and legible. Replace all missing, illegible, or damaged safety decals. When replacing parts with safety decals attached, the safety decals must also be replaced.

REPLACING SAFETY DECALS: Clean the area of application with nonflammable solvent, then wash the same area with soap and water. Allow the surface to fully dry. Remove the backing from the safety decal, exposing the adhesive surface. Apply the safety decal to the position shown in the diagram above and smooth out any bubbles.

9638 12-2-14-4

DECALS




DANGER! PINCH POINTS
PART #40149



WARNING! HIGH PRESSURE FLUID
PART #40151



WARNING!
PART #4468



WARNING! READ MANUAL
PART #40150



STAND CLEAR
PART #40161




DANGER! FLYING DEBRIS
PART #40719 (LARGE)
PART #40855 (SMALL)




WARNING! HAZARDOUS DUST
PART #41043

DECALS



ANGLE INDICATOR
PART #40723




SELECTOR VALVE OPERATION
MANUAL CONTROLS ONLY
PART #40799




DEPTH INDICATOR
PART #40773


NOTE: CONTACT YOUR LOCAL DEALER TO PURCHASE MODEL NUMBER AND LOGO DECALS



***OPERATION CONTROLS**
PART #40776
BRADCO STYLE



***OPERATION CONTROLS**
PART #40777
NEW HOLLAND STYLE



***OPERATION CONTROLS**
PART #40774
CASE STYLE

*** NOTE: OPERATION DECALS ON HYDRAULICALLY CONTROLLED UNITS ARE PURCHASED ACCORDING TO THE MULTI-FUNCTION ELECTRIC CONTROL HANDLE YOUR UNIT IS EQUIPPED WITH.**

PRE-OPERATION

12" COLD PLANERS

SKID STEER

The BRADCO 12" planers are not designed for use on high flow skid steers. Cold planer and skid steer compatibility is determined by the recommended lifting capacity of your skid steer.

WARNING! Do NOT attach or operate any attachment that exceeds the recommended lifting capacity of your skid steer.



Skid steers MUST be equipped with auxiliary boom hydraulics to run the cold planer.

WARNING! EXPOSURE TO RESPIRABLE CRYSTALLINE SILICA DUST ALONG WITH OTHER HAZARDOUS DUSTS MAY CAUSE SERIOUS OR FATAL RESPIRATORY DISEASE.



This attachment is designed to plane (mill) rock, concrete and asphalt, causing high levels of dust. It is recommended to use dust suppression, dust collection and if necessary personal protective equipment during the operation of the planer or of any attachment that may cause high levels of dust!

IMPORTANT

Concrete and masonry products contain silica sand. Quartz, which is a form of silica and the most common mineral in the earth's crust, is associated with many types of rock.

Some activities that silica dust may be present in the air include demolition, sweeping, loading, sawing, hammering, drilling or planing of rock, concrete or masonry.

It is recommended to use dust suppression (such as water), dust collection (such as a vacuum) along with personal protective equipment if necessary during the operation of any attachment that may cause high levels of silica dust.

OPTIONS


PLANING OPTIONS	Concrete Picks.....	Contact Dealer
	2.5" (Slot Cutter) Drum.....	#100641

PRE-OPERATION

12" COLD PLANERS

NOMENCLATURE

Throughout this manual, reference is made to various attachment components. The purpose of this section is to acquaint you with the various names of these components. This knowledge will be helpful when reading through the manual or when ordering service parts.



INSTALLATION INSTRUCTIONS

GENERAL INFORMATION

The following instructions will help mount your SP300 Planer onto your skid steer loader. The planer uses the quick-attach system for ease of installation. Therefore, if you know how to attach your loader bucket, attaching the cold planer should prove no problem.

Remember to read all safety warnings, decals and operating instructions before operating the attachment. If there is any portion of this manual that you do not understand, contact your dealer.

WARNING! THE 12" PLANERS ARE NOT DESIGNED FOR USE ON HIGH FLOW HYDRAULIC SYSTEMS.



DO NOT ATTACH OR OPERATE ANY ATTACHMENT THAT EXCEEDS THE RECOMMENDED LIFTING CAPACITY OF YOUR SKID STEER.

INSTALLATION INSTRUCTIONS

1. Remove the shipping banding from around the planer and skid.
2. Remove any attachments from the front of the loader.
3. Following all standard safety practices and the instructions for installing an attachment in your skid steer operator's manual, install the Planer onto your skid steer.

NOTE: It is important to make sure the locking mechanism on your quick attach is engaged, therefore locking the attachment onto the skid steer.

4. Lower the unit to the ground, and remove the key.
5. Relieve any pressure from the auxiliary hydraulic system and after making sure that there is not any foreign matter on the hydraulic couplers, connect the power and return couplers to the auxiliary hydraulic system of your skid steer loader.
6. Connect the electrical wire harness from the cold planer to the auxiliary electrical connector on the front of the skid steer (if so equipped). If your skid steer is not equipped with an electrical connector and you are using the BRADCO control handle, connect the wiring harness to the control handle and place the control handle inside of the skid steer. Connect the power cord from the BRADCO control handle to a power source on the skid steer.

NOTE: Do not operate the cold planer from outside of the skid steer operator's station.

DANGER! ELECTROCUTION HAZARD



Provide electrical power to the control handle by following your skid steer manufacturer's recommended procedures. The electrical circuit must be fused with a 10 amp fuse to prevent machine damage and serious personal injury or death.

INSTALLATION INSTRUCTIONS

7. Following all standard safety practices, start the skid steer and run all cylinders through their full cycle to purge any air from the system. Check that all controls function in accordance with the operating control decal.
8. If your planer is equipped with an optional water kit, install the female coupler supplied to your water line coming from the water tank on the skid steer. Connect the female coupler to the male coupler on the planer water kit.

Your Planer is now installed and ready for operation.

DISCONNECT INSTRUCTIONS

1. Center the planer on the sideshift frame.
2. Adjust the depth to ground level.
3. Set the planer on a firm level surface.
4. Following the Safety Shutdown Procedures: stop the engine and set the parking brake. Relieve any pressure in the hydraulic lines.
5. Disconnect the power and return hoses from the auxiliary hydraulics.
6. Disconnect the electrical cord assembly from the skid steer.
7. Turn the ball valve to the off position on the water kit, and then disconnect the water line at the couplers.
8. Following all standard safety practices and the instructions for disconnecting an attachment in your skid steer operator's manual, disconnect the planer from your skid steer.
9. Connect the couplers on the attachment together to prevent contaminants from entering the hydraulic system and secure off the ground to prevent damage.

OPERATING INSTRUCTIONS

INTENDED USE: This unit is designed to plane / mill horizontal surfaces consisting of rock, concrete and asphalt. Use in any other way is considered contrary to the intended use.

GENERAL INFORMATION

The Planer attaches to the toolbar/quick-attach mechanism of your skid steer loader. Due to this arrangement, thorough knowledge of the skid steer controls is necessary for machine operation. Read and understand your skid steer operator's manual for information regarding skid steer operation before attempting to use the planer.

Check the surface to be planed. The standard all purpose picks can be used to mill both asphalt and concrete. There are optional concrete picks that are recommended if the planer is to be used extensively for concrete. These picks do not perform as well when milling asphalt, especially in warmer weather.


Review the job at hand and determine the required depth and tilt of the cut, and also the sideshift position of the planer. Best performance is obtained when the cold planer is in the center position. Sideshift should be used when visibility is a determining factor, such as milling around manholes or when milling next to an obstacle such as a building. **NOTE: Although the wheel assemblies are standard, they may be removed when distance is a factor such as milling next to an obstacle or building.**

WARNING!  **EXPOSURE TO RESPIRABLE CRYSTALLINE SILICADUST ALONG WITH OTHER HAZARDOUS DUSTS MAY CAUSE SERIOUS OR FATAL RESPIRATORY DISEASE.**

It is recommended to use dust suppression, dust collection and if necessary personal protective equipment during the operation of the planer or of any attachment that may cause high levels of dust.

OPERATING INSTRUCTIONS

1. Clear area of all bystanders.
2. Lift the planer until the drum is off the ground and start planer rotation. (Teeth at the bottom of the drum must be moving in the same forward direction that the planer travels.)



NOTE: Mill only when the skid steer is traveling forward. Do not operate when traveling in reverse.

OPERATING INSTRUCTIONS

NOTE: On planers with hydraulic controls, hydraulic cylinders adjust the depth of the planer, sideshift the planer to the left or right and tilt the planer. On manual-control planers, turnbuckles adjust the depth and tilt of the planer and a hydraulic cylinder side shifts the planer to the left or right.

3. On hydraulically-controlled planers; increase engine RPM and with the drum turning you can make any necessary adjustments to the side shift. On manually-controlled units; after making sure the selector valve handle is in the correct position make any necessary adjustments to the side shift and then return the handle to the operating position. Do not side shift the cold planer during milling operation. Once the desired side shift position has been achieved you are ready to begin. The drum will not cut in a side to side motion. Tilt and Depth control can both be activated during milling on hydraulically-controlled units but must be set before milling on manually-controlled units.

IMPORTANT: The drum **MUST** be turning to make any hydraulic adjustment to the planer on hydraulically-controlled units.

4. Position the planer at the desired starting point. Set the depth gauge to the desired depth mark on the planer. Maximum depth of each cut is determined by the type of material, the horsepower of the skid steer being used and the size of the planer. It is recommended for maximum performance that you start at approximately .75" to 1" in concrete and 1.50" to 2" in asphalt.
5. With the engine at full RPM and the planer rolled back, lower the loader arms completely down and slowly roll out the planer until the weight of the planer is resting on the mainframe assembly. Continue to exert down pressure by rolling the loader forward until the front wheels of the planer are on the ground and the front wheels of the skid steer are raised approximately 2-3 inches off the planing surface to assure sufficient pressure for stable operation.

NOTE: It is recommended to try a sample cut until the desired depth is achieved.

6. Slowly advance forward.

NOTE: If drum stalls you have been traveling too fast or cutting too deep. Back out of the cut until the drum restarts (make necessary adjustments) and then continue operation.

NOTE: If the drum tends to ride up out of the cut, decrease travel speed, be sure the planer is level (front to back) and exert down pressure until the planer is riding on the wheel assemblies. For optimal cutting and reduced vibration, maintain down pressure on the planer with both planer wheels on the ground when cutting.

NOTE: Avoid side to side movement while planing as this may cause excessive drum wear or planetary failure.

7. When you have reached the end of the pass, stop the skid steer and raise the planer out of the cut. Reposition skid steer for the next cut and repeat steps 4, 5 & 6. If you are not starting a new cut, raise the planer and retract the drum into the planer housing. Do not transport the planer with drum turning.

OPERATING INSTRUCTIONS

CAUTION!



Periodic observation must be made of the transmission oil temperature indicator when planing with standard flow hydraulic systems. Depending on the ambient temperature and the duty cycle of the machine, hydraulic oil may overheat.

If indicator comes on, shut off the cold planer and allow the skid steer to idle until the temperature falls below 160° Fahrenheit.



If the system continues running hot, it may be necessary to clean any debris from the oil cooler and radiator. Check engine air filter and also the hydraulic oil level.

Continuous or excessive overheating may cause machine damage.

SPECIAL APPLICATIONS


LARGE AREA

With BRADCO'S 12" standard flow planer's depth control design it is recommended that you plane pass 1, 3, and 5 and then go back and reset the planer for passes 2 and 4 in critical depth situations. An alternative method when even depth control is not as critical is to continually mill large areas with one wheel riding above ground level.



MILLING AROUND MANHOLES

For best visibility when milling around manholes, it is recommended that the planer be shifted to the right. The planer is not designed to mill around tight corners, therefore it is recommended that four to six passes be made on each side of the manhole. NOTE: The more passes, the less amount of manual clean-up required.



9630 9-2-09-3


OPERATING INSTRUCTIONS

DEEP CUTS

To achieve a deep cut the width of the drum, make the first cut at the recommended depth for the material being milled, and then reposition the planer at the beginning of the pass and reset for double the recommended depth. Example: Make the first cut with the depth controls set at 2" and then set the depth control at 4" for the second pass and so on and so forth until the desired depth is obtained.

To achieve a 4" cut of a large area it is recommended to cut each pass to the required depth by following the procedure above and leaving approximately 6" between passes. Clear the spoil from the area and reposition the planer for the middle cut. NOTE: Due to the width of the middle cuts, it may be possible to achieve up to a 4" cut in one pass. Removing the spoil between cuts will enhance the productivity of the planer and maintain an even cut.

If trying to achieve a critical cutting depth, it is recommended that the spoil from one cut be cleared away before making another pass. This will eliminate the possibility of the planer riding on and off the spoil and creating an uneven surface.



MILLING TAPER CUTS

When adding to or joining new paved surfaces to existing paving, a taper cut may be required at the interacting joints so the new paving would appear seamless.

Example: To achieve a taper cut from 0" to 4" over a 2' distance with a 12" wide cold planer, it is recommended that you set the planer at 2" and the tilt set at 4° for the first pass. Then make a second pass with the planer set at 4" and the tilt still at 4°.

OPERATING INSTRUCTIONS

STORAGE

- Clean the unit thoroughly, removing all mud, dirt, and grease.
- Inspect for visible signs of wear, breakage, or damage. Order any parts required and make the necessary repairs to avoid delays upon removal from storage.
- Tighten loose nuts, capscrews and hydraulic connections.
- Coat exposed portions of the cylinder rods with grease.
- Lubricate grease fittings.
- Seal hydraulic system from contaminants and secure all hydraulic hoses off the ground to help prevent damage.
- Replace decals that are damaged or in unreadable condition.
- Store unit in a dry and protected place. Leaving the unit outside will materially shorten its life.

Additional Precautions for Long Term Storage:


- Touch up all unpainted surfaces with paint to prevent rust.

REMOVAL FROM STORAGE

- Remove cover.
- Wash unit and replace any damaged and/or missing parts.
- Lubricate grease fittings.
- Check hydraulic hoses for damage and replace as necessary.

LIFT POINTS

Lifting points are identified by lifting decals where required. Lifting at other points is unsafe and can damage attachment. Do not attach lifting accessories around cylinders or in any way that may damage hoses or hydraulic components. See Diagram



- Attach lifting accessories to unit at recommended lifting points.
- Bring lifting accessories together to a central lifting point.
- Lift gradually, maintaining the equilibrium of the unit.


OPERATING INSTRUCTIONS

WARNING! Use lifting accessories (chains, slings, ropes, shackles and etc.) that are capable of supporting the size and weight of your attachment. Secure all lifting accessories in such a way to prevent unintended disengagement. Failure to do so could result in the attachment falling and causing serious personal injury or death.



TIE DOWN POINTS

Tie down points are identified by tie down decals where required. Securing to trailer at other points is unsafe and can damage attachment. Do not attach tie down accessories around cylinders or in any way that may damage hoses or hydraulic components. See Diagram



- Attach tie down accessories to unit as recommended.
- Check unit stability before transporting.

WARNING! Verify that all tie down accessories (chains, slings, ropes, shackles and etc.) are capable of maintaining attachment stability during transporting and are attached in such a way to prevent unintended disengagement or shifting of the unit. Failure to do so could result in serious personal injury or death.



TRANSPORTING

Follow all local government regulations that may apply along with recommended tie down points and any equipment safety precautions at the front of this handbook when transporting your attachment.

LUBRICATION

GENERAL INFORMATION

Economical and efficient operation of any machine is dependent upon regular and proper lubrication of all moving parts with a quality lubricant. Neglect leads to reduced efficiency, wear, breakdown and needless replacement of parts.

All parts provided with grease fittings should be lubricated, as indicated. If any grease fittings are missing, replace them immediately. Clean all fittings thoroughly before using the grease gun.

IMPORTANT: Avoid excessive greasing. Dirt collects on exposed grease and greatly increases wear. After greasing, wipe off excessive grease from fittings.

LUBRICATION SYMBOLS

The following symbols are used on the lubrication diagram below. It is reproduced here with its meaning for your convenience.



Lubricate daily or every 8 hours of operation, whichever comes last, with SAE Multi-Purpose Lubricant or equivalent SAE Multi-Purpose type grease.





Lubricate weekly or every 40 hours of operation, whichever comes last, with SAE Multi-Purpose Lubricant or equivalent SAE Multi-Purpose type grease.



CAUTION! SHUT OFF ENGINE BEFORE LUBRICATING EQUIPMENT.

The planer planetary is a sealed unit. If there are any signs of oil leaks, please contact your nearest BRADCO dealer before carrying out any repairs, as there can be other causes for seal leaks. The planetary uses the Gear Oil (Castrol SP 320) for lubrication of gears and bearings. The Digga planetary holds approximately 2 quarts of gear oil while the Auburn planetary uses approximately .56 quarts of gear oil.

The Digga planetary gear oil should be drained and replaced after the first 8 months of use. Thereafter, every 12 months or 2500 hours - whichever comes first. The Auburn planetary gear oil should be drained and replaced after the first 50 hours of use. Thereafter every 12 months or 1000 hours - whichever comes first.



9632 12-2-14-4


MAINTENANCE & SERVICE

GENERAL INFORMATION

Regular maintenance is the key to long equipment life and safe operation. Maintenance requirements have been reduced to an absolute minimum. However, it is very important that these maintenance functions be performed as described below.

WARNING!  **Never do any maintenance to the planer while it is running. Exercise the MANDATORY SAFETY SHUTDOWN PROCEDURE BEFORE working on or around the planer.**

Procedure	Daily	Every 40 Hours	Every 1000 Hours (Yearly)	Every 2500 Hours (Yearly)
Hydraulic Oil - Check prime mover hydraulic system for adequate oil levels.	✓			
Hardware - Check for tightness (see Bolt Torque Specifications)	✓			
Hardware - Replace any missing or damaged bolts or nuts with approved replacement parts.	✓			
Hydraulic System - Check for leaks and tighten as necessary. Check for damage and replace as needed.	✓			
Decals - Check for missing or damaged safety decals and replace as necessary.	✓			
Check picks for freedom of rotation, flat spots and wear. Replace worn or missing picks or any picks that are not moving freely or have flat spots.	✓			
Inspect attachment for any worn parts or cracked welds. Repair as required.	✓			
Lubricate grease fittings on Wheel pivot pins.	✓			
Lubricate grease fittings on cylinder ends (if equipped).		✓		
Change oil in planetary.			AUBURN PLANETARY	DIGGA PLANETARY

WARNING!  **Escaping fluid under pressure can have sufficient force to penetrate the skin causing serious personal injury. Fluid escaping from a very small hole can be almost invisible. Use a piece of cardboard or wood, rather than hands to search for suspected leaks.**

Keep unprotected body parts, such as face, eyes, and arms as far away as possible from a suspected leak. Flesh injected with hydraulic fluid may develop gangrene or other permanent disabilities.

If injured by injected fluid, see a doctor at once. If your doctor is not familiar with this type of injury, ask him to research it immediately to determine proper treatment.

MAINTENANCE & SERVICE

IMPORTANT: When replacing parts use only factory approved replacement parts. Manufacturer will not claim responsibility for use of unapproved parts or accessories and/or other damages as a result of their use.

PICK REPLACEMENT

Picks should be replaced if you are changing to a different application pick, they are broken, worn, flat spot or are seized in the pick holder and do not rotate freely.

WARNING! Always wear safety glasses with side shields when striking metal. Failure to heed could result in serious injury to the eyes or other parts of the body.




Do all pick maintenance through access door.


DO NOT attempt to check the picks with the planer in a raised position without first blocking up the planer. Before exercising the **MANDATORY SAFETY SHUTDOWN PROCEDURE** find an elevated surface to set the planer on or have a second person block the planer in place before shutting down the machine.

1. Open front access door.
2. Rotate the drum until the pick to be removed is conveniently accessible.
3. Hold the extracting tool (pick puller) in one hand and place the jaws in the groove of the pick, with the offset handle pointing away from the pick holder.
4. Using a lead hammer or rubber-headed mallet, hit the raised pad on the tool until the pick starts to move. Continue tapping until the pick is removed.
5. Insert the new pick into the jaws of the extracting tool (pick puller) so that the raised pad of the tool is pointing in the same direction as the pick point.
6. Position the new pick in the pick holder on the drum and with a lead hammer or rubber-headed mallet, hit the raised pad of the tool to start the pick into the pick holder. (Clean out any foreign material from the pick holder before installing the new pick.)
7. Once the pick is started into the pick holder strike the tool pad one strong blow to pop the pick into the holder.

PICK REMOVAL



PICK INSTALLATION




The pick is properly seated when its shoulder is against the face of the pick holder. Check to be sure the pick rotates freely.

MAINTENANCE & SERVICE


CHANGING THE DRUM

Due to the weight of the unit, place the planer in a convenient location with a hoist available for lifting the planer off the drum.


1. Remove the right side plate by first removing the two bolts in the retainer and then loosen the six .50" bolts on the clamp plates. Slide the right side plate off.



2. Remove the hex nuts securing the drum to the planetary.
3. Using a pry bar, pry the drum off of the planetary and slide out until the drum clears the planetary. lift the planer off of the drum.
4. Install the new drum by positioning it over the studs on the planetary and installing the existing hex nuts using Locktite 271 (Red) and torquing to 155 ft. lbs.
5. Reinstall the right side plate.



PRY DRUM OFF OF PLANETARY



CHANGING THE PLANETARY


To gain access to the planetary the drum must first be removed. Follow the above procedure for removing the drum.

1. Tag and disconnect the power and return hoses along from the hydraulic motor and plug the motor ports to prevent contaminants from entering the hydraulic system.
2. Remove the .50" bolts securing the planetary to the planer and remove the planetary.

MAINTENANCE & SERVICE

3. Check to be sure the new planetary is filled with oil. If not, fill with Castrol SP 320 gear oil. (Digga Planetary - 2 quarts and Auburn Planetary - .56 quart. Auburn planetary should be half full when mounted level horizontally.) Do not overfill.
4. Remove the hydraulic motor from the planetary. Scrap any silicone from the hydraulic motor and apply new RV 10 silicone to the motor to seal the connection between the motor and the planetary. Bolt the hydraulic motor onto the new planetary using the existing hardware.
5. Position the new planetary into the planer housing and reinstall the .50" capscrews, flat washers and lock nuts. Check to ensure that the hydraulic motor is in the correct position with the ports turned up. Torque to specification
6. Reinstall the drum as described in "CHANGING THE DRUM".
7. Re-connect the hydraulic hoses and fittings to the motor.

**TAG AND REMOVE
HYDRAULIC HOSES
FROM MOTOR**



**REMOVE PLANETARY FROM PLAN-
ER BY UNBOLTING .50" X 2.25"
CAPSCREWS**

CHANGING HYDRAULIC MOTOR

1. Position the planer on its side or in such a fashion that the planetary oil will not leak out when replacing the motor.
2. Tag and disconnect the power and return hoses from the hydraulic motor.
3. Remove the capscrews securing the motor to the planetary.
4. Scrape the mating surface of the planetary, removing all existing silicone, to prepare it for the new motor.
5. Apply new RV 10 silicone to the motor to seal the connection between the motor and the planetary. Bolt the new hydraulic motor onto the planetary using the existing hardware. (Check to ensure that the hydraulic motor is in the correct position with the ports turned up.) Torque to specification
6. Re-connect the hydraulic hoses and fittings to the motor.

MAINTENANCE AND SERVICE

CYLINDER SEAL REPLACEMENT




The following information is provided to assist you in the event you should need to repair or rebuild a hydraulic cylinder. When working on hydraulic cylinders, make sure that the work area and tools are clean and free of dirt to prevent contamination of the hydraulic system and damage to the hydraulic cylinders. Always protect the active part of the cylinder rod (the chrome section). Nicks or scratches on the surface of the rod could result in cylinder failure. Clean all parts thoroughly with a cleaning solvent before reassembly.

DISASSEMBLY PROCEDURE



IMPORTANT: Do not contact the active surface of the cylinder rod with the vise. Damage to the rod could result.

THREADED TYPE GLAND

1. Rotate the gland with a spanner wrench counterclockwise until the gland is free of the cylinder tube.
2. Pull the cylinder rod from the cylinder tube and inspect the piston and the bore of the cylinder tube for deep scratches or galling. If damaged, the piston AND the cylinder tube must be replaced.



3. Remove the hex nut, piston, flat washer or spacer tube (if so equipped), and gland from the cylinder rod. If the cylinder rod is rusty, scratched, or bent, it must be replaced.
4. Remove and discard all the old seals.






ASSEMBLY PROCEDURE

IMPORTANT: Replace all seals even if they do not appear to be damaged. Failure to replace all seals may result in premature cylinder failure. **NOTE:** Seal kits will service most cylinders of similar bore size and rod diameter.

1. Install the cylinder rod seal in the gland first. Be careful not to damage the seal in the process, as it is somewhat difficult to install.

NOTE: A special installation tool (Part #65349) is available to help with installing the seal. Simply fit the end of the tool over the seal so that the large prong of the tool is on the outside of the seal, and the two smaller prongs on the inside. The lip of the seal should be facing towards the tool. Rotate the handles on the tool around to wrap the seal around the end of the tool.



10356 10-13-05



MAINTENANCE AND SERVICE

Now insert the seal into the gland from the inner end. Position the seal in its groove, and release and remove the tool. Press the seal into its seat the rest of the way by hand.

2. Install the new piston ring, rod wiper, O-rings and backup washers, if applicable, on the piston.


Be careful not to damage the seals. Caution must be used when installing the piston ring. The ring must be stretched carefully over the piston with a smooth, round, pointed tool.

3. After installing the rod seal inside the gland, as shown in step #1, install the external seal.




NOTE: Threaded glands may have been equipped with a separate O-ring and backup washer system or a polypak (all in one) type seal. Current seal kits contain a polypak (all in one) type seal to replace the discarded seal types on ALL THREADED GLANDS.

4. Slide the gland onto the cylinder rod, being careful not to damage the rod wiper. Then install the spacer, or flat washer (if so equipped), small o-ring, piston, and hex nut onto the end of the cylinder rod.
5. Secure the cylinder rod (mounting end) in a vise with a support at its center. Torque the nut to the amount shown for the thread diameter of the cylinder rod (see chart).



Thread Diameter	POUNDS - FEET
7/8"	150-200
*1"	230-325
1-1/8"	350-480
1-1/4"	490-670
1-3/8"	670-900
* 1" Thread Diameter WITH 1.25" Rod Diameter	
Min. 230 ft. lbs. Max. 250 ft. lbs.	

IMPORTANT: Do not contact the active surface of the cylinder rod with the vise. Damage to the rod could result.



6. Apply a lubricant (such as Lubriplate #105) to the piston and teflon ring. Insert the cylinder rod assembly into the cylinder tube.

IMPORTANT: Ensure that the piston ring fits squarely into the cylinder tube and piston groove, otherwise the ring may be damaged and a leak will occur.

7. Use a spanner wrench to rotate the gland clockwise into the cylinder. Continue to rotate the gland with the spanner wrench until it is tight.

WARNING!



Cylinders serviced in the field are to be tested for leakage prior to the attachment being placed in work. Failure to test rebuilt cylinders could result in damage to the cylinder and/or the attachment, cause severe personal injury or even death.

TROUBLESHOOTING

<u>PROBLEM</u>	<u>POSSIBLE CAUSE</u>	<u>POSSIBLE SOLUTION</u>
Motor on the planer will not operate.	Auxiliary hoses not hooked up to the skid steer.	Engage Couplers
	Obstruction in hydraulic lines.	Remove obstruction and replace if necessary.
	Hydraulic motor damaged or seals blown.	Call Bradco service department for instructions.
	Skid steer auxiliary valve not engaged.	Engage auxiliary valve.
Drum rotates sluggishly.	Insufficient hydraulic flow from the skid steer.	Refer to skid steer's owners manual.
	Damaged quick coupler.	Replace if necessary.
	Hydraulic motor damaged or seals blown.	Call Bradco service department for instructions.
	Oil filter on skid steer is dirty.	Refer to skid steer's owners manual.
Leaking Oil.	Loose or damaged hydraulic line.	Tighten or replace.
	O-Rings on fittings damaged.	Replace if necessary.
	Hydraulic motor damaged or seals blown.	Call Bradco service department for instructions.
	Fittings loose or damaged.	Tighten or replace.
	Cylinder seals damaged.	Replace cylinder seals.
Insufficient power.	Insufficient hydraulic flow from the skid steer.	Refer to skid steer's owners manual.
	Relief valve setting adjusted too low.	Refer to skid steer's owners manual.
	Hydraulic motor damaged or seals blown.	Call Bradco service department for instructions.
	Oil filter on skid steer is dirty.	Refer to skid steer's owners manual.
Drum rotates in the wrong direction.	Hoses from the valve to the motor incorrectly connected.	Switch hoses at the motor end.
Excessive vibration during planing operation.	Picks are worn or broken.	Visually inspect the picks and replace as necessary.
	Picks contain flat spots or are not rotating freely.	Visually inspect the picks and replace as necessary.
	Insufficient down force due to incorrect operating procedure.	Refer to the Operating section of this manual.

TROUBLESHOOTING

<u>PROBLEM</u>	<u>POSSIBLE CAUSE</u>	<u>POSSIBLE SOLUTION</u>
Excessive oil temperature.	Hydraulic oil level too low.	Refer to skid steer's owners manual
	Obstruction in hydraulic lines.	Remove obstruction and replace if necessary.
	Hydraulic oil or oil filter in skid steer is dirty.	Refer to skid steer's owners manual.
	Relief valve setting adjusted too low.	Refer to skid steer's owners manual.
	Couplers not engaged.	Engage couplers.
A Hydraulic cylinder not operating.	Insufficient hydraulic flow from the skid steer.	Refer to skid steer's owners manual.
	Cylinder rod bent.	Visually inspect the cylinder for damage.
	Cylinder seals damaged.	Replace cylinder seals.
	Obstruction in hydraulic lines.	Remove obstruction and replace if necessary.
All hydraulic cylinders not functioning.	Blown fuse on skid steer.	Refer to skid steer's owners manual.
	Damaged electrical wiring.	Test and replace if necessary.
	Solenoid valve spool bent.	Replace spool.
	Nut on Solenoid valve too tight	Loosen nut.
Hydraulic cylinders only operating in one direction.	Contaminants in the hydraulic system and solenoid valve.	Remove spool from solenoid valve and check for foreign material. Clean or replace.
		Remove spool from solenoid valve and check seals for damage. Replace if necessary.
	Damaged electrical wiring.	Test and replace if necessary.
	Solenoid valve spool bent.	Replace spool.
	Nut on Solenoid valve too tight	Loosen nut.

BOLT TORQUE SPECIFICATIONS

GENERAL TORQUE SPECIFICATION TABLES


Use the following charts when determining bolt torque specifications when special torques are not given. Always use grade 5 or better when replacing bolts.

SAE BOLT TORQUE SPECIFICATIONS




NOTE: The following torque values are for use with extreme pressure lubricants, plating or hard washer applications. Increase torque 15% when using hardware that is unplated and either dry or lubricated with engine oil.

Bolt Size		SAE GRADE 5 TORQUE				SAE GRADE 8 TORQUE				Bolt head identification marks as per grade. NOTE: Manufacturing Marks Will Vary
		Pounds Feet		Newton-Meters		Pounds Feet		Newton-Meters		
Inches	Millimeters	UNC	UNF	UNC	UNF	UNC	UNF	UNC	UNF	
1/4	6.35	8	9	11	12	10	13	14	18	
5/16	7.94	14	17	19	23	20	25	27	34	
3/8	9.53	30	36	41	49	38	46	52	62	
7/16	11.11	46	54	62	73	60	71	81	96	
1/2	12.70	68	82	92	111	94	112	127	152	
9/16	14.29	94	112	127	152	136	163	184	221	
5/8	15.88	128	153	174	207	187	224	254	304	
3/4	19.05	230	275	312	373	323	395	438	536	
7/8	22.23	340	408	461	553	510	612	691	830	
1	25.40	493	592	668	803	765	918	1037	1245	
1-1/8	25.58	680	748	922	1014	1088	1224	1475	1660	
1-1/4	31.75	952	1054	1291	1429	1547	1700	2097	2305	
1-3/8	34.93	1241	1428	1683	1936	2023	2312	2743	3135	
1-1/2	38.10	1649	1870	2236	2535	2686	3026	3642	4103	




GRADE 2



GRADE 5






GRADE 8



METRIC BOLT TORQUE SPECIFICATIONS


NOTE: The following torque values are for use with metric hardware that is unplated and either dry or lubricated with engine oil. Reduce torque 15% when using hardware that has extreme pressure lubricants, plating or hard washer applications.

Bolt head identification marks as per grade.		
		

Size of Bolt	Grade No.	Pitch (mm)	Pounds Feet	Newton-Meters	Pitch (mm)	Pounds Feet	Newton-Meters
M6	5.6	1.0	3.6-5.8	4.9-7.9	-	-	-
	8.8		5.8-4	7.9-12.7		-	-
	10.9		7.2-10	9.8-13.6		-	-
M8	5.6	1.25	7.2-14	9.8-19	1.0	12-17	16.3-23
	8.8		17-22	23-29.8		19-27	25.7-36.6
	10.9		20-26	27.1-35.2		22-31	29.8-42
M10	5.6	1.5	20-25	27.1-33.9	1.25	20-29	27.1-39.3
	8.8		34-40	46.1-54.2		35-47	47.4-63.7
	10.9		38-46	51.5-62.3		40-52	54.2-70.5
M12	5.6	1.75	28-34	37.9-46.1	1.25	31-41	42-55.6
	8.8		51-59	69.1-79.9		56-68	75.9-92.1
	10.9		57-66	77.2-89.4		62-75	84-101.6
M14	5.6	2.0	49-56	66.4-75.9	1.5	52-64	70.5-86.7
	8.8		81-93	109.8-126		90-106	122-143.6
	10.9		96-109	130.1-147.7		107-124	145-168
M16	5.6	2.0	67-77	90.8-104.3	1.5	69-83	93.5-112.5
	8.8		116-130	157.2-176.2		120-138	162.6-187
	10.9		129-145	174.8-196.5		140-158	189.7-214.1
M18	5.6	2.0	88-100	119.2-136	1.5	100-117	136-158.5
	8.8		150-168	203.3-227.6		177-199	239.8-269.6
	10.9		175-194	237.1-262.9		202-231	273.7-313
M20	5.6	2.5	108-130	146.3-176.2	1.5	132-150	178.9-203.3
	8.8		186-205	252-277.8		206-242	279.1-327.9
	10.9		213-249	288.6-337.4		246-289	333.3-391.6

SPECIFICATIONS

12" COLD PLANER



DESCRIPTION	SPECIFICATION
	12"
A. Overall Width	51.94"
B. Overall Height	32.15"
C. Overall Length	43.86"
D. Planing Width	12.00"
E. Planing Depth	0"-5.00"
Drum Diameter	19.00"
Number of Picks (Full size drum)	37
Weight (lbs)	1500#
Hydraulic Flow Requirement	15-22 GPM
Operating Pressure	2500-3000 PSI


**THIS PAGE
IS INTENTIONALLY
BLANK**

LIMITED WARRANTY

In order to provide you with the most UP-TO-DATE Warranty information, Paladin Warranty Statement and Warranty Procedures along with Warranty Registration and Claim Forms have been moved to our website at www.paladinattachments.com.

SP300 PLANER ASSEMBLY

12" COLD PLANER ASSEMBLY #19070



SP300 PLANER ASSEMBLY

12" COLD PLANER ASSEMBLY #19070


<u>ITEM</u>	<u>REQ'D</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
1	2	1146	.75" UNC X 3.75" Hex Capscrew
2	2	1507	.75" Lock Washer
3	2	1518	.75" Flat Washer
4	2	100400	Pin Boss
5	2	100407	Clamp Boss
6	1	100396	Pivot Cam Bracket
7	2	1650	Snap Ring
8	2	6623	Thrust Washer
9	1	100399	Pivot Pin
10	1	100805	Cannister
	1	6616	Grease Fitting
	2	100491	Plug (Water Line Ports)
11	1	19071	Right Side Plate
12	2	1102	.50" UNC X 5.00" Hex Capscrew
13	1	100932	Latch
	2	1043	.38" UNC X 1.00" Hex Capscrew
	2	1503	.38" Lock Washer
	2	1514	.38" Flat Washer
	2	1226	.38" UNC Hex Nut
14	1	19751	Door
15	2	17666	Spacer Tube
16	2	1646	.50" Hard Flat Washer
17	2	1841	.50" UNC Deformed Lock Nut
18	3	1044	.38" UNC X 1.25" Hex Capscrew
	3	1503	.38" Lock Washer
	3	1514	.38" Flat Washer
	3	1226	.38" UNC Hex Nut
19	1	101188	Rubber Deflector
20	8	100394	Shim
21	4	100393	Spacer
22	8	10086	.50" UNC X 2.25" Hex Capscrew - Grade 8
	8	1646	.50" Hard Flat Washer
	8	1841	.50" UNC Deformed Lock Nut
23	1	19072	Left Side Plate
24	1	100533	Depth Indicator
	2	1043	.38 UNC X 1.00" Hex Capscrew
	2	1503	.38" Lock Washer
25	14	1505	.50" Lock Washer
26	12	1093	.50" UNC C 2.25" Hex Capscrew
27	4	100392	Clamp Plate
28	1	100808	Hydraulic Motor
	1	100813	Motor Gasket
	**	19302	Replacement Seal Kit
29	1	101765	Planetary - Digga (Serial Number #388377 and DOWN) (Serial Number #569064 and UP)
	1	117873	Planetary - Auburn (Serial Number #388378 UP TO #569063)
30	2	1089	.50" UNC X 1.25" Hex Capscrew
31	1	19706	Drum Assembly with Teeth
32	6	1840	Hex Nut
33	1	74491	Bushing

* Field replacement of internal motor seals voids warranty.

9488 3-30-22-6

SP300 PLANER ASSEMBLY

12" COLD PLANER ASSEMBLY #19070





SP300 PLANER ASSEMBLY

12" COLD PLANER ASSEMBLY #19070

<u>ITEM</u>	<u>REQ'D</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
1	10	1965	.50" UNC X 2.50" Hex Capscrew - Grade 8
2	12	1505	.50" Lock Washer
3	2	19281	Clamp Plate
4	4	19284	Wear Strip
5	2	19283	Shim
6	2	19282	Spacer Plate
7	1	89491	Side Shift Hitch Frame
8	1	19162	Pivot Plate
9	2	19246	Clamp Boss
10	4	1503	.38" Lock Washer
11	4	1049	.38" UNC X 2.50" Hex Capscrew
12	1	19745	Pivot Bushing
13	1	19247	Cap Plate
14	2	1964	.50" UNC X 1.75" Hex Capscrew - Grade 8
15	1	100213	Pick Extracting Tool

DRUM AND PICK OPTIONS



DRUM AND PICK OPTIONS

DRUM OPTIONS (INCLUDES STANDARD ALL-PURPOSE PICKS)


<u>#1 DESCRIPTION</u>	<u>PART NUMBER</u>	<u>PICK QTY</u>
12" Standard Drum	19706	37
2.50" Slot Cutter Drum	100641	18

<u>#2 DESCRIPTION</u>	<u>PART NUMBER</u>
General Purpose Application Pick	18546

<u>#3 DESCRIPTION</u>	<u>PART NUMBER</u>
Concrete Application Pick with Washer	18547

WHEEL ASSEMBLY

ASSEMBLY #18702




WHEEL ASSEMBLY

ASSEMBLY #18702

<u>ITEM</u>	<u>REQ'D</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
1	1	17667	Wheel Mounting Bracket
2	3	1505	.50" Lock Washer
3	3	1811	.50" UNC X 1.50" Hex Capscrew - Grade 8
4	1	1514	.38" Flat Washer
5	1	1503	.38" Lock Washer
6	1	1042	.38 "UNC X .75" Hex Capscrew
7	1	17673	Pivot Pin
8	1	6616	Grease Fitting
9	1	17671	Wheel
10	1	61079	Washer

HYDRAULIC ASSEMBLY

HYDRAULIC ASSEMBLIES #100458 and #38749
(HYDRAULIC CONTROLS)



HYDRAULIC ASSEMBLY


HYDRAULIC ASSEMBLIES #100458 and #38749
(HYDRAULIC CONTROLS)

<u>ITEM</u>	<u>REQ'D</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
1	10	6612	Snap Ring
2	10	57462	Thrust Washer
3	1	57461	Pivot Pin 1.00" X 3.72"
4	1	89520	Cylinder Assembly (Depth Control)
5	1	57457	Pivot Pin 1.00" X 4.88"
6	7	3434	90° Elbow 6MBo-6MJ
7	2	38155	Hose .25" X 12" 6FJX-6FJX
8	2	89978	Pivot Pin 1.00" X 3.25"
9	1	19202	Cylinder Assembly (Side Shift)
10	2	38345	Hose .25" X 48" 6FJX-6FJX45°
11	1	19632	Male Coupler (May Vary on Different Skid-Steers)
12	1	22518	Female Coupler (May Vary on Different Skid-Steers)
13	1	38237	Hose .75" X 60" 12FJX-12MBo-HS (Assembly #100458)
	1	38752	Hose .75" X 70" 12FJX-12MBo-HS (Assembly #38749)
14	1	38237	Hose .75" X 60" 12FJX-12MBo-HS (Assembly #100458)
	1	38752	Hose .75" X 70" 12FJX-12MBo-HS (Assembly #38749)
15	1	30140	90° Elbow - Long 6MBo-6MJ
16	1	19675	3-Function Control Valve
	2	1034	.31" UNC X 4.00" Hex Capscrew
	2	1524	.31" Flat Washer
	2	1934	.31" UNC Deformed Lock Nut
17	1	100950	Valve Cover
18	1	100434	BRADCO Control Handle Assembly
	1	17173	Wiring Harness (Control Box to Battery)
19	1	19644	Wiring Harness
20	8	3457	Straight Connector 6MBo-6MJ
21	1	19738	Valve Cover
22	2	1837	.38" UNC Deformed Lock Nut
	2	1525	.38" Flat Washer
	2	1043	.38" UNC X 1.00" Hex Capscrew
23	2	1525	.38" Flat Washer
	2	1503	.38" Lock Washer
	2	1043	.38" UNC X 1.00" Hex Capscrew
24	1	37262	Hose .25" X 18" 6FJX-6FJX
25	1	37016	Hose .25" X 15" 6FJX-6FJX
26	1	89530	Cylinder Assembly (Tilt Control)
27	2	3409	Straight Adapter 16MBo-12MJ
28	2	38238	Hose .62" X 56" 10FJX-12FJX 90°-HS
29	1	100780	Valve
30	2	30051	90° Elbow 16MBo-12MJ
31	2	38239	Hose .25" X 48" 6FJX-6FJX 90°
32	2	3431	Straight Connector 10MBo-10MJ

9503 8-7-14-3

HYDRAULIC ASSEMBLY

HYDRAULIC ASSEMBLIES #19038 and #38748
(MANUAL CONTROLS)



9626 8-7-14-4


HYDRAULIC ASSEMBLY

HYDRAULIC ASSEMBLIES #19038 and #38748 (MANUAL CONTROLS)

<u>ITEM</u>	<u>REQ'D</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
1	1	19632	Male Coupler (May Vary on Different Skid-Steers)
2	1	22518	Female Coupler (May Vary on Different Skid-Steers)
3	2	3432	Straight Connector 12MBo-10MJ (Assembly #19038)
	2	3419	Straight Connector 12MBo-12MJ (Assembly #38748)
4	2	38238	Hose .62" X 56" 10FJX-12FJX 90° (Assembly #19038)
	2	38751	Hose .75" X 70" 12FJX-12FJX 90° (Assembly #38748)
5	1	57457	Pin 1.00" X 4.75"
6	1	19773	Turnbuckle Rod - 7.28" LH - Depth Control
7	1	19768	Turnbuckle
8	1	19771	Turnbuckle Rod - 7.28" RH - Depth Control
9	1	101198	Wrench
10	10	6612	Snap ring
11	10	57462	Thrust Washer
12	1	57461	Pin 1.00" X 3.72"
13	2	30098	90° Elbow XL 12MBo-12MJ
14	1	38241	Hose .62" X 29" 12FJX-12FJX-HS
15	1	30351	90° Elbow 12MBo-12MBo
16	2	2254	Check Valve
17	1	38242	Hose .62" X 34" 12FJX-12MBo-HS
18	1	22600	90° Elbow 12MBo-12MJ
19	1	22566	Selector Valve
	2	1051	.38" UNC X 3.00" Hex Capscrew
	2	1503	.38" Lock Washer
	2	1226	.38" UNC Hex Nut
20	2	30201	Straight Adapter 12MBo-6MJ
21	1	38106	Hose .25" X 22" 6FJX-6FJX 90°
22	1	38005	Hose .25" X 30" 6FJX-6FJX 90°
23	2	3434	90° Elbow 6MBo-6MJ
24	2	89978	Pin 1.00" X 3.25"
25	1	19202	Side Shift Cylinder Assembly
26	1	19765	Turnbuckle Rod - 5.97" RH - Tilt Control
27	1	82838	Turnbuckle
28	1	19767	Turnbuckle Rod - 5.97" LH - Tilt Control
29	2	30350	Tee 12MJ-12MJ-12MBo
30	2	38240	Hose .62" X 29" 12FJX-12FJX-HS

PLANETARY ASSEMBLY - AUBURN

PLANETARY ASSEMBLY #117873



12903 10-27-14

PLANETARY ASSEMBLY - AUBURN

PLANETARY ASSEMBLY #117873


<u>ITEM</u>	<u>REQ'D</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
1	1	119944	Shaft
	6	119943	Wheel Bolt
2	1	117933	Oil Seal
3	1	117935	Bearing Cone
4	1	117936	Bearing Cup
5	1	117937	Thrust Washer
6	1	117938	Lock Washer
7	1	117951	Bearing Nut
8	1	117952	Carrier
9	1	117953	Sun Gear
10	1	22439	Thrust Washer
11	2	117954	Pipe Plug
12	12	22432	Flat Washer
13	12	10258	.38" UNC X 3.00" Sockethead Capscrew - Grade 8
14	1	119443	Bearing Cup
15	1	119444	Bearning Cone

**WARRANTY NOTICE:
ANY ATTEMPT TO DISASSEMBLE OR
MAKE FIELD REPAIRS TO THE
PLANETARY WILL VOID WARRANTY.
CONTACT YOUR DEALER/DISTRIBUTOR.**

12904 10-27-14

CYLINDER ASSEMBLY

ASSEMBLY #19202



9509 9-3-09-2

CYLINDER ASSEMBLY


ASSEMBLY #19202

<u>ITEM</u>	<u>REQ'D</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
1	1	1483	Hex Nut
2	1	50252	Piston
3	1	5421	Washer
4	1	19203	Cylinder Tube
5	1	77458	Cylinder Gland
6	1	19205	Cylinder Rod
7	1	4645*	O-Ring
8	1	4644*	Piston Ring
9	1	4641*	O-Ring
10	1	4509*	O-Ring
11	1	4510*	Back-Up Washer
12	1	45219*	Poly-Pak Seal
13	1	45250*	O-Ring
14	1	45389*	Rod Wiper

NOTE: Seal kit #45617 includes all parts marked with an asterisk (*). Parts are not sold separately.

CYLINDER ASSEMBLY

ASSEMBLY #89520



CYLINDER ASSEMBLY


ASSEMBLY #89520

<u>ITEM</u>	<u>REQ'D</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
1	1	1482	Hex Nut
2	1	6992	Piston
3	1	52644	Washer
4	1	89521	Cylinder Tube
5	1	89527	Cylinder Gland
6	1	89522	Cylinder Rod
7	1	4637*	O-Ring
8	1	4636*	Piston Ring
9	1	4635*	O-Ring
10	1	4633*	O-Ring
11	1	4634*	Back-Up Washer
12	1	45262*	Poly-Pak Seal
13	1	4981*	Rod Wiper

NOTE: Seal kit #45581 includes all parts marked with an asterisk (*). Parts are not sold separately.

CYLINDER ASSEMBLY

ASSEMBLY #89530



CYLINDER ASSEMBLY


ASSEMBLY #89530

<u>ITEM</u>	<u>REQ'D</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
1	1	1482	Hex Nut
2	1	6992	Piston
3	1	52644	Washer
4	1	89531	Cylinder Tube
5	1	89527	Cylinder Gland
6	1	89532	Cylinder Rod
7	1	4637*	O-Ring
8	1	4636*	Piston Ring
9	1	4635*	O-Ring
10	1	4633*	O-Ring
11	1	4634*	Back-Up Washer
12	1	45262*	Poly-Pak Seal
13	1	4981*	Rod Wiper

NOTE: Seal kit #45581 includes all parts marked with an asterisk (*). Parts are not sold separately.

WATER NOZZLE KIT

ASSEMBLY #19216



WATER NOZZLE KIT

ASSEMBLY #19216

<u>ITEM</u>	<u>REQ'D</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
1	1	30215	Female Quick Coupler
2	1	30214	Male Quick Coupler
3	1	30338	Bushing
4	1	30231	Ball Valve
5	1	30216	Hose Barb
6	6	30227	Hose Clamp
7	14'	19217	Reinforced PVC Hose (Cut to Length)
8	2	30223	Tee Nozzlebody
9	1	30222	90° Nozzlebody
10	3	30221	Inline Nozzlebody Strainer
11	3	30229	Spray Nozzle Tip
12	3	30225	Nozzlebody Wing Cap



PALADINTM
CONSTRUCTION GROUP



EU DECLARATION OF CONFORMITY

I, the undersigned, on behalf of:

Manufacturer/Technical Document Holder

Paladin Construction Group
2800 N. Zeeb Road
Dexter, MI 48130 USA
Phone: 734-996-9116
Fax: 734-996-9014

hereby declare that the following product:

Description of Equipment:

**Hydraulically operated Tree Spade for compact tool carrier (CTC),
mini excavator and skid steer loader applications. Used for
removing or transplanting trees and shrubs.**

Attachment Model:

2030, 2625, 3625, 4425, 2415, 3215, 4415

Serial Number:

Conforms to:

**2006/42/EC Machinery Directive;
EN ISO 4254-1; EN ISO 14121-1;
EN ISO 12100-1; EN ISO 12100-2;
EN ISO 2867; EN 982**

Certification method:

**Self-certified, per Annex
V of the Directive**

Name and address of the person in the Community authorized to compile the technical construction file:

**STANLEY Dubuis
17-19, rue Jules Berthanneau-BP 3406 41034
Blois Cedex, France**

At Delhi, Signature, Title, Date

Signature: _____

Title: _____

Date: _____

UKCA DECLARATION OF CONFORMITY

The undersigned, representing the following manufacturer:

Manufacturer: Paladin Attachments
2800 N Zeeb Rd.
Dexter, MI 48130
United States

Declares that the product(s)

Product identification:

Description: HYDRAULIC CABLES CUTTING TOOLS WITH 18V RECHARGEABLE BATTERY
Model: **BCP040GC - BCP045GC - BCP055GC - BCP065CC - BCP085G+**
Serial number: L-00001 à L-99999

Conforms to the UK Regulations:

The supply of Machinery (Safety) Regulations 2008, S.I. 2008/1597 (as amended)
Electromagnetic Compatibility Regulations, 2016, S.I. 2016/1091 (as amended)
The Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations 2012, S.I. 2012/3032 (as amended)

Designated Standards:

SI 2008/1597 NF EN ISO 15744 (December 2008)
NF EN ISO 3744 (February 2012)
NF EN ISO 20643 (September 2008)
NF EN ISO 11201 (December 2010)
NF EN 12096 (September 1997)

SI 2016/1091 EN 62233 (September 2013)
EN 55014-1 (June 2017)
EN 55014-2 (July 2015)
EN 62311 (October 2008)

S.I. 2012/3032 NF EN IEC 63000 (December 2018)

The undersigned is responsible for compilation of the technical file and makes this declaration on behalf of DUBUIS.

Signature

Blois, July 28, 2021

Patrick VERVIER,

Engineering Manager