




## OPERATOR'S MANUAL

# DOZER BLADE ATP46 & ATP67 Hydraulic Angle and Tilt

**FOR  
COMPACT TOOL CARRIERS**



SERIAL NUMBER: \_\_\_\_\_

MODEL NUMBER: \_\_\_\_\_

Manual Number: OM651  
Part Number: 75551  
Rev. 7



# TABLE OF CONTENTS

|                                                       |       |
|-------------------------------------------------------|-------|
| <b>PREFACE</b> .....                                  | 3     |
| <b>SAFETY PRECAUTIONS</b>                             |       |
| SAFETY STATEMENTS .....                               | 5     |
| GENERAL SAFETY PRECAUTIONS .....                      | 5-7   |
| EQUIPMENT SAFETY PRECAUTIONS .....                    | 8-9   |
| <b>DECALS</b>                                         |       |
| DECAL PLACEMENT .....                                 | 10    |
| DECALS .....                                          | 11    |
| <b>PREOPERATION</b>                                   |       |
| NOMENCLATURE .....                                    | 12    |
| <b>INSTALLATION</b>                                   |       |
| INSTALLATION .....                                    | 13    |
| DETACHING .....                                       | 13    |
| <b>OPERATION</b>                                      |       |
| GENERAL INFORMATION .....                             | 14    |
| ANGLING THE BLADE .....                               | 14    |
| OPERATING TIPS .....                                  | 14    |
| STORAGE .....                                         | 14    |
| REMOVE FROM STORAGE .....                             | 15    |
| LIFT POINTS .....                                     | 15    |
| TIE DOWN POINTS .....                                 | 15    |
| <b>MAINTENANCE AND SERVICE</b>                        |       |
| GENERAL INFORMATION .....                             | 16    |
| EVERY 8 HOURS .....                                   | 16    |
| EVERY 40 HOURS .....                                  | 16    |
| CYLINDER SEAL REPLACEMENT - THREADED TYPE GLAND ..... | 17-18 |
| <b>TROUBLESHOOTING</b> .....                          | 19    |
| <b>SPECIFICATIONS</b>                                 |       |
| SPECIFICATIONS .....                                  | 20    |
| BOLT TORQUE SPECIFICATIONS .....                      | 21    |
| <b>PARTS / LIMITED WARRANTY</b> .....                 | 23    |

**THIS PAGE  
IS INTENTIONALLY  
BLANK**

# PREFACE

## GENERAL COMMENTS

Congratulations on the purchase of your new BRADCO product! This product was carefully designed and manufactured to give you many years of dependable service. Only minor maintenance (such as cleaning and lubricating) is required to keep it in top working condition. Be sure to observe all maintenance procedures and safety precautions in this manual and on any safety decals located on the product and on any equipment on which the attachment is mounted.

This manual has been designed to help you do a better, safer job. Read this manual carefully and become familiar with its contents.

**WARNING!** Never let anyone operate this unit without reading the "Safety Precautions" and "Operating Instructions" sections of this manual.



Always choose hard, level ground to park the vehicle on and set the brake so the unit cannot roll.

Unless noted otherwise, right and left sides are determined from the operator's control position when facing the attachment.

**NOTE:** The illustrations and data used in this manual were current (according to the information available to us) at the time of printing, however, we reserve the right to redesign and change the attachment as may be necessary without notification.

## BEFORE OPERATION

The primary responsibility for safety with this equipment falls to the operator. Make sure the equipment is operated only by trained individuals that have read and understand this manual. If there is any portion of this manual or function you do not understand, contact your local authorized dealer or the manufacturer to obtain further assistance. Keep this manual available for reference. Provide the manual to any new owners and/or operators.

## SAFETY ALERT SYMBOL



This is the "Safety Alert Symbol" used by this industry. This symbol is used to warn of possible injury. Be sure to read all warnings carefully. They are included for your safety and for the safety of others working with you.

## SERVICE

Use only manufacturer replacement parts. Substitute parts may not meet the required standards.

Record the model and serial number of your unit on the cover of this manual. The parts department needs this information to insure that you receive the correct parts.

## SOUND AND VIBRATION

Sound pressure levels and vibration data for this attachment are influenced by many different parameters: some items are listed below (not inclusive):

- prime mover type, age, condition, with or without cab enclosure and configuration
- operator training, behavior, stress level
- job site organization, working material condition, environment

Based on the uncertainty of the prime mover, operator, and job site, it is not possible to get precise machine and operator sound pressure levels or vibration levels for this attachment.

**NOTE:** A list of all Paladin Patents can be found at <http://www.paladinattachments.com/patents.asp>.

**THIS PAGE  
IS INTENTIONALLY  
BLANK**

## SAFETY STATEMENTS



THIS SYMBOL BY ITSELF OR WITH A WARNING WORD THROUGHOUT THIS MANUAL IS USED TO CALL YOUR ATTENTION TO INSTRUCTIONS INVOLVING YOUR PERSONAL SAFETY OR THE SAFETY OF OTHERS. FAILURE TO FOLLOW THESE INSTRUCTIONS CAN RESULT IN INJURY OR DEATH.



### **DANGER**

THIS SIGNAL WORD INDICATES A HAZARDOUS SITUATION WHICH, IF NOT AVOIDED, WILL RESULT IN DEATH OR SERIOUS INJURY.



### **WARNING**

THIS SIGNAL WORD INDICATES A HAZARDOUS SITUATION WHICH, IF NOT AVOIDED, COULD RESULT IN DEATH OR SERIOUS INJURY.



### **CAUTION**

THIS SIGNAL WORD INDICATES A HAZARDOUS SITUATION WHICH, IF NOT AVOIDED, COULD RESULT IN MINOR OR MODERATE INJURY.

### **NOTICE**

NOTICE IS USED TO ADDRESS PRACTICES NOT RELATED TO PHYSICAL INJURY.

## GENERAL SAFETY PRECAUTIONS

### **WARNING!**



#### **READ MANUAL PRIOR TO INSTALLATION**

Improper installation, operation, or maintenance of this equipment could result in serious injury or death. Operators and maintenance personnel should read this manual, as well as all manuals related to this equipment and the prime mover thoroughly before beginning installation, operation, or maintenance. **FOLLOW ALL SAFETY INSTRUCTIONS IN THIS MANUAL AND THE PRIME MOVER'S MANUAL(S).**



#### **READ AND UNDERSTAND ALL SAFETY STATEMENTS**

Read all safety decals and safety statements in all manuals prior to operating or working on this equipment. Know and obey all OSHA regulations, local laws, and other professional guidelines for your operation. Know and follow good work practices when assembling, maintaining, repairing, mounting, removing, or operating this equipment.



#### **KNOW YOUR EQUIPMENT**

Know your equipment's capabilities, dimensions, and operations before operating. Visually inspect your equipment before you start, and never operate equipment that is not in proper working order with all safety devices intact. Check all hardware to ensure it is tight. Make certain that all locking pins, latches, and connection devices are properly installed and secured. Remove and replace any damaged, fatigued, or excessively worn parts. Make certain all safety decals are in place and are legible. Keep decals clean, and replace them if they become worn or hard to read.

## GENERAL SAFETY PRECAUTIONS

### WARNING!



#### PROTECT AGAINST FLYING DEBRIS

Always wear proper safety glasses, goggles, or a face shield when driving pins in or out, or when any operation causes dust, flying debris, or any other hazardous material.

### WARNING!



#### LOWER OR SUPPORT RAISED EQUIPMENT

Do not work under raised booms without supporting them. Do not use support material made of concrete blocks, logs, buckets, barrels, or any other material that could suddenly collapse or shift positions. Make sure support material is solid, not decayed, warped, twisted, or tapered. Lower booms to ground level or on blocks. Lower booms and attachments to the ground before leaving the cab or operator's station.


### WARNING!



#### USE CARE WITH HYDRAULIC FLUID PRESSURE

Hydraulic fluid under pressure can penetrate the skin and cause serious injury or death. Hydraulic leaks under pressure may not be visible. Before connecting or disconnecting hydraulic hoses, read your prime mover's operator's manual for detailed instructions on connecting and disconnecting hydraulic hoses or fittings.

- Keep unprotected body parts, such as face, eyes, and arms as far away as possible from a suspected leak. Flesh injected with hydraulic fluid may develop gangrene or other permanent disabilities.
- If injured by injected fluid, see a doctor at once. If your doctor is not familiar with this type of injury, ask him to research it immediately to determine proper treatment.
- Wear safety glasses, protective clothing, and use a piece of cardboard or wood when searching for hydraulic leaks. **DO NOT USE YOUR HANDS!** **SEE ILLUSTRATION.**





## GENERAL SAFETY PRECAUTIONS

### WARNING!



#### DO NOT MODIFY MACHINE OR ATTACHMENTS

Modifications may weaken the integrity of the attachment and may impair the function, safety, life, and performance of the attachment. When making repairs, use only the manufacturer's genuine parts, following authorized instructions. Other parts may be substandard in fit and quality. Never modify any ROPS (Roll Over Protective Structure) or FOPS (Falling Object Protective Structure) equipment or device. Any modifications must be authorized in writing by the manufacturer.

### WARNING!



#### SAFELY MAINTAIN AND REPAIR EQUIPMENT

- Do not wear loose clothing or any accessories that can catch in moving parts. If you have long hair, cover or secure it so that it does not become entangled in the equipment.
- Work on a level surface in a well-lit area.
- Use properly grounded electrical outlets and tools.
- Use the correct tools for the job at hand. Make sure they are in good condition for the task required.
- Wear the protective equipment specified by the tool manufacturer.



#### SAFELY OPERATE EQUIPMENT

Do not operate equipment until you are completely trained by a qualified operator in how to use the controls, know its capabilities, dimensions, and all safety requirements. See your machine's manual for these instructions.

- Keep all step plates, grab bars, pedals, and controls free of dirt, grease, debris, and oil.
- Never allow anyone to be around the equipment when it is operating.
- Do not allow riders on the attachment or the prime mover.
- Do not operate the equipment from anywhere other than the correct operator's position.
- Never leave equipment unattended with the engine running, or with this attachment in a raised position.
- Do not alter or remove any safety feature from the prime mover or this attachment.
- Know your work site safety rules as well as traffic rules and flow. When in doubt on any safety issue, contact your supervisor or safety coordinator for an explanation.

### WARNING!



#### CALIFORNIA PROPOSITION 65 WARNING

This product may contain a chemical known to the state of California to cause cancer, or birth defects or other reproductive harm. [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov)

## EQUIPMENT SAFETY PRECAUTIONS

### WARNING!



#### KNOW WHERE UTILITIES ARE

Observe overhead electrical and other utility lines. Be sure equipment will clear them. When digging, call your local utilities for location of buried utility lines, gas, water, and sewer, as well as any other hazard you may encounter.

### WARNING!



#### EXPOSURE TO RESPIRABLE CRYSTALLINE SILICA DUST ALONG WITH OTHER HAZARDOUS DUSTS MAY CAUSE SERIOUS OR FATAL RESPIRATORY DISEASE.

It is recommended to use dust suppression, dust collection and if necessary personal protective equipment during the operation of any attachment that may cause high levels of dust.

### WARNING!



#### REMOVE PAINT BEFORE WELDING OR HEATING

Hazardous fumes/dust can be generated when paint is heated by welding, soldering or using a torch. Do all work outside or in a well ventilated area and dispose of paint and solvent properly. Remove paint before welding or heating.

When sanding or grinding paint, avoid breathing the dust. Wear an approved respirator. If you use solvent or paint stripper, remove stripper with soap and water before welding. Remove solvent or paint stripper containers and other flammable material from area. Allow fumes to disperse at least 15 minutes before welding or heating.

### WARNING!



#### END OF LIFE DISPOSAL

At the completion of the useful life of the unit, drain all fluids and dismantle by separating the different materials (rubber, steel, plastic, etc.). Follow all federal, state and local regulations for recycling and disposal of the fluid and components.

#### OPERATING THE BLADE

- Do not exceed the capacity of your prime mover when pushing loads or objects.
- Operate only from the operator's station. Do not operate the blade when standing beside the machine.
- Prime mover may feel heavy in the front with the added weight of the blade. Stability and handling may be affected.
- Reduce speed when driving over rough terrain, on a slope, or turning, to avoid overturning the vehicle.
- An operator must not use drugs or alcohol, which can change his or her alertness or coordination. An operator taking prescription or over-the-counter drugs should seek medical advice on whether or not he or she can safely operate equipment.
- Before exiting the prime mover, lower the attachment to the ground, apply the brakes, turn off the prime mover's engine, and remove the key.
- Use the blade only for its designed purpose. Do not use it to pull objects, as a battering ram, or attach ropes or chains to the unit.

# EQUIPMENT SAFETY PRECAUTIONS



## TRANSPORTING THE BLADE

- Allow for the added width and length when transporting so as not to catch unit on obstacles.
- Carry blade low when transporting to lower its center of gravity. Drive slowly over rough ground and on slopes.
- When driving on public roads use safety lights, reflectors, Slow Moving Vehicle signs etc., to prevent accidents. Check local government regulations that may affect you.
- Do not drive close to ditches, excavations, etc., cave in could result.
- Do not smoke when refueling the prime mover. Allow room in the fuel tank for expansion. Wipe up any spilled fuel. Secure cap tightly when done.
- When transporting on a trailer: Secure attachment at recommended tie down locations using tie down accessories that are capable of maintaining attachment stability.



## MAINTAINING THE BLADE

- Before performing maintenance, lower the attachment to the ground, apply brakes, turn off the engine, and remove the key.
- Never perform any work on the attachment unless you are authorized and qualified to do so. Always read the operator service manuals before any repair is made. After completing maintenance or repair, check for correct functioning of the attachment. If not functioning properly, always tag "DO NOT OPERATE" until all problems are corrected.
- Worn, damaged, or illegible safety decals must be replaced. New safety decals can be ordered from Paladin.
- Never make hydraulic repairs while the system is under pressure. Serious personal injury or death could result.
- Never work under a raised attachment.

# DECALS


## DECAL PLACEMENT

### GENERAL INFORMATION

The following diagrams show the location of all the decals used on your attachment. The decals are identified by their part numbers, with the reductions of the actual decals shown on the following pages. Use this information to order replacements for lost or damaged decals. Be sure you understand all decals before operating the attachment. They contain information you need to know for attachment safety.

**IMPORTANT:** Keep all safety decals clean and legible. Replace all missing, or damaged safety decals. When replacing parts with safety decals attached, the safety decals must also be replaced.


**REPLACING SAFETY DECALS:** Clean the area of application with a nonflammable solvent, then wash the same area with soap and water. Allow the surface to dry. Remove the backing from the safety decal, exposing the adhesive surface. Apply the safety decal to the position shown in the diagram, and smooth out any bubbles.



## DECALS DECALS



**DANGER! PINCH POINTS**  
**PART #40149**




**LIFT POINT**  
**PART #50-0769**



**WARNING! HIGH PRESSURE FLUID**  
**PART #40151**



**MADE IN USA**  
**PART #4338**



**GREASE 40 HOURS**  
**PART #4085**

**NOTE: CONTACT YOUR LOCAL DEALER FOR MODEL NUMBER AND LOGO DECALS.**

# PREOPERATION


## HYDRAULIC BLADE

### GENERAL INFORMATION

The BRADCO hydraulic angle and tilt blades were designed to be easy to use and maintain. There are three different hydraulic kits available: dual auxiliary hydraulics, selector valve, and electrical solenoid valve kit. They are all operated by the loaders auxiliary hydraulics and the blade mounts to the toolbar / quick attach mechanism for easy mounting.

### NOMENCLATURE

Throughout this manual, reference is made to various blade components. Study the following diagrams to acquaint yourself with the various names of these components. This knowledge will be helpful when reading through this manual or when ordering service parts.



# INSTALLATION

## ATTACHING

Your blade was shipped complete with the appropriate mounting for your specific unit, and the hydraulic hoses and couplers were installed for the kit you ordered.

Install the blade by following your power unit operator's manual for installing an attachment.

**WARNING!** To Avoid Serious Personal Injury, make sure the blade is securely latched to the attachment mechanism of your unit. Failure to do so could result in separation of the bucket from the unit.



If using the selector valve hydraulic kit, mount the selector valve to the arm of the loader. If powering the blade with the electrical solenoid valve hydraulic kit, connect the electrical wire harness to the battery of the skid-steer, and position the control box in a location accessible by the operator. Connect the hydraulic quick couplers to the auxiliary hydraulics, and route the hoses in such a fashion as to prevent chafing and pinching.

**WARNING!** When working around batteries, remember that all of the exposed metal parts are "live". Never lay a metal object across the terminals, because a spark or short circuit may result.



**DANGER!** BATTERY ACID CAUSES SEVERE BURNS. Batteries contain sulfuric acid. Avoid contact with skin, eyes, or clothing. Antidote: EXTERNAL - flush with water. INTERNAL - drink large quantities of water or milk. Follow with milk of magnesia, beaten egg or vegetable oil. Call physician immediately. EYES - flush with water for 15 minutes and get prompt medical attention.



Start engine and slowly cycle the cylinders several times to purge system of air and check for proper hydraulic connection, hose routing, and hose length.

Check the attachment for proper assembly, installation, and hydraulic leaks.

## DETACHING

On firm level ground, lower the boom arms completely down on the frame until the blade is level and approximately 2" off the ground.

Turn off the engine. Move the control levers back and forth to relieve pressure in line. Disconnect couplers. NOTE: If using the electrical solenoid valve, disconnect the wire harness coming from the battery to the control box, and attach the control box onto the blade assembly.

**NOTE:** Connect couplers together or install caps to prevent contaminants from entering the hydraulic system.

Follow your power unit operator's manual for detaching (removing) an attachment.

**NOTE:** Frequent lubrication of grease fittings at the end of the cylinder and pivot points with a multi-purpose grease will greatly increase life of the product.

# OPERATION

## OPERATING INSTRUCTIONS

Simplicity of operation is one of the key features of the BRADCO blades. There are only a few controls that affect the blade. It is important however, to be familiar with, and know the controls and adjustments on both the blade and loader.

The blade mounts to the quick attach mechanism of your loader. Due to this arrangement, thorough knowledge of the loader controls is necessary for blade operation. Read your loader operator's manual for information regarding loader operation before attempting to use the blade.

## ANGLING AND TILTING THE BLADE

The blade is angled and tilted hydraulically by cylinders connected from the blade to the pivot frame and tilt frame. The blade can be angled 35° left or right.

The angle and tilt cylinders are activated by the auxiliary hydraulic system controls. If using the selector valve, the position of the valve handle determines the cylinder being activated. If using the electric solenoid valve, the cylinder being activated is determined by the toggle switch on the control box.

**CAUTION!** Drive slowly and with caution when operating the blade. The force of the impact if the blade hits an immovable object could cause damage to the blade and loader, and injury to the operator.



## OPERATING TIPS

Clean the area of trash, branches, and rocks before operation to prevent equipment damage.

Always begin with the slowest ground speed possible. Increase speed if surrounding conditions permit.

Always use full throttle (maximum engine speed).

When leveling, scraping, and surface stripping, lower the cutting edge to the ground, the blade will bite into the ground as you move forward.

Watch for holes, rocks, or other hidden hazards. Always inspect area prior to operation.

## STORAGE

1. Clean the unit thoroughly, removing all mud, dirt, and grease.
2. Inspect for visible signs of wear, breakage, or damage. Order any parts required, and make the necessary repairs or avoid delays when starting next season.
3. Tighten loose nuts, capscrews, and hydraulic connections.
4. Seal hydraulic system from contaminants and secure all hydraulic hoses off the ground to help prevent damage..
5. Coat the exposed portions of the cylinder rods with grease.
6. Store the unit in a dry and protected place. Leaving the unit outside will materially shorten its life.

## Additional Precautions for Long Term Storage:

Touch up all unpainted surfaces with paint to prevent rust.



# OPERATION


## REMOVE FROM STORAGE

1. Remove Cover
2. Wash unit and replace any damaged and/or missing parts.
3. Lubricate grease fittings.
4. Check hydraulic hoses for damage and replace as necessary.

## LIFT POINTS

Lifting points are identified by lifting decals where required. Lifting at other points is unsafe and can damage attachment. Do not attach lifting accessories around cylinders or in any way that may damage hoses or hydraulic components. See Diagram

- Attach lifting accessories to unit at recommended lifting points.
- Bring lifting accessories together to a central lifting point.
- Lift gradually, maintaining the equilibrium of the unit.




**WARNING!** Use lifting accessories (chains, slings, ropes, shackles and etc.) that are capable of supporting the size and weight of your attachment. Secure all lifting accessories in such a way to prevent unintended disengagement. Failure to do so could result in the attachment falling and causing serious personal injury or death.



## TIE DOWN POINTS

Tie down points are identified by tie down decals where required. Securing to trailer at other points is unsafe and can damage attachment. Do not attach tie down accessories around cylinders or in any way that may damage hoses or hydraulic components. See Diagram

- Attach tie down accessories to unit as recommended.
- Check unit stability before transporting.



**WARNING!** Verify that all tie down accessories (chains, slings, ropes, shackles and etc.) are capable of maintaining attachment stability during transporting and are attached in such a way to prevent unintended disengagement or shifting of the unit. Failure to do so could result in serious personal injury or death.



# MAINTENANCE & SERVICE

## GENERAL INFORMATION

Regular maintenance is the key to long equipment life and safe operation. Maintenance requirements have been reduced to the absolute minimum. However, it is very important that these maintenance functions be performed as described below.


| Procedure                                                                              | Daily | Every 40 Hours |
|----------------------------------------------------------------------------------------|-------|----------------|
| Check all bolts and nuts for tightness.                                                | ✓     |                |
| Replace any missing bolts or nuts with approved replacement parts.                     | ✓     |                |
| Check hydraulic system for hydraulic oil leaks. See procedure below.                   | ✓     |                |
| Visually inspect the machine for worn parts or cracked welds, and repair as necessary. | ✓     |                |
| Lubricate all grease fittings.                                                         |       | ✓              |

**WARNING!** Escaping fluid under pressure can have sufficient force to penetrate the skin, causing serious personal injury. Fluid escaping from a very small hole can be almost invisible. Use a piece of cardboard or wood, rather than hands, to search for suspected leaks.



Keep unprotected body parts, such as face, eyes, and arms as far away as possible from a suspected leak. Flesh injected with hydraulic fluid may develop gangrene or other permanent disabilities.

If injured by injected fluid, see a doctor at once. If your doctor is not familiar with this type of injury, ask him to research it immediately to determine proper treatment.



**IMPORTANT:** When replacing parts, use only factory approved replacement parts. Manufacturer will not claim responsibility for use of unapproved parts or accessories, and/or other damages as a result of their use.

# MAINTENANCE AND SERVICE

## CYLINDER SEAL REPLACEMENT




The following information is provided to assist you in the event you should need to repair or rebuild a hydraulic cylinder. When working on hydraulic cylinders, make sure that the work area and tools are clean and free of dirt to prevent contamination of the hydraulic system and damage to the hydraulic cylinders. Always protect the active part of the cylinder rod (the chrome section). Nicks or scratches on the surface of the rod could result in cylinder failure. Clean all parts thoroughly with a cleaning solvent before reassembly.

### DISASSEMBLY PROCEDURE



**IMPORTANT:** Do not contact the active surface of the cylinder rod with the vise. Damage to the rod could result.

#### THREADED TYPE GLAND

1. Rotate the gland with a spanner wrench counterclockwise until the gland is free of the cylinder tube.
2. Pull the cylinder rod from the cylinder tube and inspect the piston and the bore of the cylinder tube for deep scratches or galling. If damaged, the piston AND the cylinder tube must be replaced.



3. Remove the hex nut, piston, flat washer or spacer tube (if so equipped), and gland from the cylinder rod. If the cylinder rod is rusty, scratched, or bent, it must be replaced.
4. Remove and discard all the old seals.






### ASSEMBLY PROCEDURE

**IMPORTANT:** Replace all seals even if they do not appear to be damaged. Failure to replace all seals may result in premature cylinder failure. **NOTE:** Seal kits will service most cylinders of similar bore size and rod diameter.

1. Install the cylinder rod seal in the gland first. Be careful not to damage the seal in the process, as it is somewhat difficult to install.

**NOTE:** A special installation tool (Part #65349) is available to help with installing the seal. Simply fit the end of the tool over the seal so that the large prong of the tool is on the outside of the seal, and the two smaller prongs on the inside. The lip of the seal should be facing towards the tool. Rotate the handles on the tool around to wrap the seal around the end of the tool.



Rotate the handles on the tool around to wrap the seal around the end of the tool.

10356 10-13-05



# MAINTENANCE AND SERVICE

Now insert the seal into the gland from the inner end. Position the seal in its groove, and release and remove the tool. Press the seal into its seat the rest of the way by hand.

2. Install the new piston ring, rod wiper, O-rings and backup washers, if applicable, on the piston.


Be careful not to damage the seals. Caution must be used when installing the piston ring. The ring must be stretched carefully over the piston with a smooth, round, pointed tool.

3. After installing the rod seal inside the gland, as shown in step #1, install the external seal.




**NOTE:** Threaded glands may have been equipped with a separate O-ring and backup washer system or a polypak (all in one) type seal. Current seal kits contain a polypak (all in one) type seal to replace the discarded seal types on ALL THREADED GLANDS.

4. Slide the gland onto the cylinder rod, being careful not to damage the rod wiper. Then install the spacer, or flat washer (if so equipped), small o-ring, piston, and hex nut onto the end of the cylinder rod.
5. Secure the cylinder rod (mounting end) in a vise with a support at its center. Torque the nut to the amount shown for the thread diameter of the cylinder rod (see chart).



| Thread Diameter                              | POUNDS - FEET |
|----------------------------------------------|---------------|
| 7/8"                                         | 150-200       |
| *1"                                          | 230-325       |
| 1-1/8"                                       | 350-480       |
| 1-1/4"                                       | 490-670       |
| 1-3/8"                                       | 670-900       |
| * 1" Thread Diameter WITH 1.25" Rod Diameter |               |
| Min. 230 ft. lbs. Max. 250 ft. lbs.          |               |

**IMPORTANT:** Do not contact the active surface of the cylinder rod with the vise. Damage to the rod could result.



6. Apply a lubricant (such as Lubriplate #105) to the piston and teflon ring. Insert the cylinder rod assembly into the cylinder tube.

**IMPORTANT:** Ensure that the piston ring fits squarely into the cylinder tube and piston groove, otherwise the ring may be damaged and a leak will occur.

7. Use a spanner wrench to rotate the gland clockwise into the cylinder. Continue to rotate the gland with the spanner wrench until it is tight.

## WARNING!




Cylinders serviced in the field are to be tested for leakage prior to the attachment being placed in work. Failure to test rebuilt cylinders could result in damage to the cylinder and/or the attachment, cause severe personal injury or even death.

# TROUBLESHOOTING

| PROBLEM                                                               | POSSIBLE CAUSE                                                     | POSSIBLE SOLUTION                                                     |
|-----------------------------------------------------------------------|--------------------------------------------------------------------|-----------------------------------------------------------------------|
| Blade fails to angle or tilt.                                         | Obstruction in hydraulic line.                                     | Remove obstruction or re-place.                                       |
|                                                                       | Hydraulic couplers not completely connected.                       | Check and tighten couplers.                                           |
|                                                                       | Hydraulic couplers malfunctioning or non-compatible.               | Replace.                                                              |
|                                                                       | Defective hydraulic cylinder.                                      | Replace cylinder.                                                     |
| Blade angling or tilting too slowly.                                  | Cold oil.                                                          | Warm oil with engine at idle.                                         |
|                                                                       | Engine speed too slow.                                             | Open throttle.                                                        |
|                                                                       | Oil leaking past cylinder packings.                                | Replace cylinder seals.                                               |
|                                                                       | Restriction in valve. (If so equipped.)                            | Clean or replace.                                                     |
| Blade fails to maintain angle or tilt.                                | Broken or leaking hydraulic lines.                                 | Replace broken hose and check for leaks.                              |
|                                                                       | Oil leaking past cylinder packings.                                | Replace cylinder seals.                                               |
|                                                                       | Internal leak in valve. (If so equipped.)                          | Clean or replace.                                                     |
| External leaking.                                                     | Cylinder seals damaged.                                            | Replace and Repair.                                                   |
|                                                                       | Broken or loose hydraulic fittings or line.                        | Check for leaks and repair or replace.                                |
|                                                                       | Spool in valve leaking.                                            | Replace seals.                                                        |
| Blade functions in one circuit only.                                  | No electrical power to the blade solenoid valve. (If so equipped.) | Check for proper connection in control box and power from skid-steer. |
|                                                                       | Selector valve set to opposite operation. (If so equipped.)        | Position selector valve to correct operation.                         |
| Blade functions in one circuit only WITH power to the solenoid valve. | Blade valve malfunctioning.                                        | Replace and Repair.                                                   |
|                                                                       | Spool in valve sticking.                                           | Clean or Replace.                                                     |

# SPECIFICATIONS

## HYDRAULIC BLADES



**SPECIFICATIONS AND DESIGN ARE SUBJECT TO CHANGE WITHOUT NOTICE AND WITHOUT LIABILITY THEREFORE.**

| SPECIFICATIONS                                            |             |        |
|-----------------------------------------------------------|-------------|--------|
| DESCRIPTION                                               | ATP46       | ATP67  |
| A. Width from Centerline to Inside Edge @ 30° Angle.....  | 22.50"..... | 31.25" |
| B. Blade Width @ 30° Angle .....                          | 40.00"..... | 57.75" |
| C. Width from Centerline to Outside Edge @ 30° Angle..... | 17.50"..... | 26.50" |
| D. Overall Width .....                                    | 46.75"..... | 67.25" |
| E. Angle - Left and Right.....                            | 30° ...     | 30°    |
| F. Overall Length .....                                   | 22.10"..... | 22.10" |
| G. Overall Height.....                                    | 16.95"..... | 16.95" |
| Weight (LBS) .....                                        | 257#.....   | 310#   |
| <b><u>CYLINDER SPECIFICATIONS</u></b>                     |             |        |
| <b>Angle Cylinder (#18024)</b>                            |             |        |
| Bore .....                                                | 2.50".....  | 2.50"  |
| Stroke .....                                              | 6.00".....  | 6.00"  |
| Rod Diameter .....                                        | 1.25".....  | 1.25"  |
| <b>Tilt Cylinder (#19336)</b>                             |             |        |
| Bore .....                                                | 2.50".....  | 2.50"  |
| Stroke .....                                              | 3.12".....  | 3.12"  |
| Rod Diameter .....                                        | 1.25".....  | 1.25"  |

# BOLT TORQUE SPECIFICATIONS

## GENERAL TORQUE SPECIFICATION TABLES

Use the following charts when determining bolt torque specifications when special torques are not given. Always use grade 5 or better when replacing bolts.

## SAE BOLT TORQUE SPECIFICATIONS

**NOTE:** The following torque values are for use with extreme pressure lubricants, plating or hard washer applications. Increase torque 15% when using hardware that is unplated and either dry or lubricated with engine oil.

| Bolt Size |             | SAE GRADE 5 TORQUE |      |               |      | SAE GRADE 8 TORQUE |      |               |      | Bolt head identification marks as per grade. NOTE: Manufacturing Marks Will Vary |
|-----------|-------------|--------------------|------|---------------|------|--------------------|------|---------------|------|----------------------------------------------------------------------------------|
|           |             | Pounds Feet        |      | Newton-Meters |      | Pounds Feet        |      | Newton-Meters |      |                                                                                  |
| Inches    | Millimeters | UNC                | UNF  | UNC           | UNF  | UNC                | UNF  | UNC           | UNF  |                                                                                  |
| 1/4       | 6.35        | 8                  | 9    | 11            | 12   | 10                 | 13   | 14            | 18   |                                                                                  |
| 5/16      | 7.94        | 14                 | 17   | 19            | 23   | 20                 | 25   | 27            | 34   |                                                                                  |
| 3/8       | 9.53        | 30                 | 36   | 41            | 49   | 38                 | 46   | 52            | 62   |                                                                                  |
| 7/16      | 11.11       | 46                 | 54   | 62            | 73   | 60                 | 71   | 81            | 96   |                                                                                  |
| 1/2       | 12.70       | 68                 | 82   | 92            | 111  | 94                 | 112  | 127           | 152  |                                                                                  |
| 9/16      | 14.29       | 94                 | 112  | 127           | 152  | 136                | 163  | 184           | 221  |                                                                                  |
| 5/8       | 15.88       | 128                | 153  | 174           | 207  | 187                | 224  | 254           | 304  |                                                                                  |
| 3/4       | 19.05       | 230                | 275  | 312           | 373  | 323                | 395  | 438           | 536  |                                                                                  |
| 7/8       | 22.23       | 340                | 408  | 461           | 553  | 510                | 612  | 691           | 830  |                                                                                  |
| 1         | 25.40       | 493                | 592  | 668           | 803  | 765                | 918  | 1037          | 1245 |                                                                                  |
| 1-1/8     | 25.58       | 680                | 748  | 922           | 1014 | 1088               | 1224 | 1475          | 1660 |                                                                                  |
| 1-1/4     | 31.75       | 952                | 1054 | 1291          | 1429 | 1547               | 1700 | 2097          | 2305 |                                                                                  |
| 1-3/8     | 34.93       | 1241               | 1428 | 1683          | 1936 | 2023               | 2312 | 2743          | 3135 |                                                                                  |
| 1-1/2     | 38.10       | 1649               | 1870 | 2236          | 2535 | 2686               | 3026 | 3642          | 4103 |                                                                                  |

GRADE 2



GRADE 5



GRADE 8



## METRIC BOLT TORQUE SPECIFICATIONS

**NOTE:** The following torque values are for use with metric hardware that is unplated and either dry or lubricated with engine oil. Reduce torque 15% when using hardware that has extreme pressure lubricants, plating or hard washer applications.

| Bolt head identification marks as per grade.                                         |                                                                                       |                                                                                       |
|--------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|
|  |  |  |

| Size of Bolt | Grade No. | Pitch (mm) | Pounds Feet | Newton-Meters | Pitch (mm) | Pounds Feet | Newton-Meters |
|--------------|-----------|------------|-------------|---------------|------------|-------------|---------------|
| M6           | 5.6       | 1.0        | 3.6-5.8     | 4.9-7.9       | -          | -           | -             |
|              | 8.8       |            | 5.8-4       | 7.9-12.7      |            | -           | -             |
|              | 10.9      |            | 7.2-10      | 9.8-13.6      |            | -           | -             |
| M8           | 5.6       | 1.25       | 7.2-14      | 9.8-19        | 1.0        | 12-17       | 16.3-23       |
|              | 8.8       |            | 17-22       | 23-29.8       |            | 19-27       | 25.7-36.6     |
|              | 10.9      |            | 20-26       | 27.1-35.2     |            | 22-31       | 29.8-42       |
| M10          | 5.6       | 1.5        | 20-25       | 27.1-33.9     | 1.25       | 20-29       | 27.1-39.3     |
|              | 8.8       |            | 34-40       | 46.1-54.2     |            | 35-47       | 47.4-63.7     |
|              | 10.9      |            | 38-46       | 51.5-62.3     |            | 40-52       | 54.2-70.5     |
| M12          | 5.6       | 1.75       | 28-34       | 37.9-46.1     | 1.25       | 31-41       | 42-55.6       |
|              | 8.8       |            | 51-59       | 69.1-79.9     |            | 56-68       | 75.9-92.1     |
|              | 10.9      |            | 57-66       | 77.2-89.4     |            | 62-75       | 84-101.6      |
| M14          | 5.6       | 2.0        | 49-56       | 66.4-75.9     | 1.5        | 52-64       | 70.5-86.7     |
|              | 8.8       |            | 81-93       | 109.8-126     |            | 90-106      | 122-143.6     |
|              | 10.9      |            | 96-109      | 130.1-147.7   |            | 107-124     | 145-168       |
| M16          | 5.6       | 2.0        | 67-77       | 90.8-104.3    | 1.5        | 69-83       | 93.5-112.5    |
|              | 8.8       |            | 116-130     | 157.2-176.2   |            | 120-138     | 162.6-187     |
|              | 10.9      |            | 129-145     | 174.8-196.5   |            | 140-158     | 189.7-214.1   |
| M18          | 5.6       | 2.0        | 88-100      | 119.2-136     | 1.5        | 100-117     | 136-158.5     |
|              | 8.8       |            | 150-168     | 203.3-227.6   |            | 177-199     | 239.8-269.6   |
|              | 10.9      |            | 175-194     | 237.1-262.9   |            | 202-231     | 273.7-313     |
| M20          | 5.6       | 2.5        | 108-130     | 146.3-176.2   | 1.5        | 132-150     | 178.9-203.3   |
|              | 8.8       |            | 186-205     | 252-277.8     |            | 206-242     | 279.1-327.9   |
|              | 10.9      |            | 213-249     | 288.6-337.4   |            | 246-289     | 333.3-391.6   |

**THIS PAGE  
IS INTENTIONALLY  
BLANK**



## PARTS

In order to provide you with the most UP-TO-DATE part information, all parts for this attachment have been moved to our website at [www.paladinattachments.com/Manuals](http://www.paladinattachments.com/Manuals). Please use these diagrams and parts lists to locate replacement parts.

When servicing your attachment, remember to use only original manufacturer replacement parts. Substitute parts may not meet the standards required for safe, dependable operation.

To facilitate parts ordering when contacting the factory, please have the product control number (PCN) or model and serial number of your product ready to ensure that you receive the correct parts for your specific attachment.

The product control number (PCN), model and serial number for your attachment should be recorded in the space provided on the cover of this manual. This information may be obtained from the serial number identification plate located on your attachment.

**NOTE: Most daily and emergency parts orders (in stock) received by 10:30 A.M. (Eastern Standard Time) will be shipped UPS Ground the same day received. UPS Next Day orders must be received by 1:30 PM (Eastern Standard Time.)**

### SERVICE DEPARTMENT

(734) 996-9116

(800) 456-7100

### For Fax and E-mail Orders

PLC\_Sales@paladinattachments.com

(734) 996-9014

## WARRANTY

In order to provide you with the most UP-TO-DATE Warranty information, Paladin Warranty Statement and Warranty Procedures along with Warranty Registration and Claim Forms have been moved to our website at [www.paladinattachments.com](http://www.paladinattachments.com).