



OPERATOR'S MANUAL

ANGLE SWEEPER M24 Series - RMRM



SERIAL NUMBER: _____

MODEL NUMBER: _____

Manual Number: 51-0046-3

Release Date: July 2019

Rev. 4

TABLE OF CONTENTS

PREFACE.....	5
SAFETY PRECAUTIONS	
Safety Statements	6
General Safety Precautions.....	6-8
Equipment Safety Precautions	9-10
DECALS.....	11-12
INSTALLATION	
Draw Bar Style & Installation	13
Installaton	13-17
Manual Angle Installation.....	18
Hydraulic Angle Installation	18-19
Power (PTO) Shaft Adjustment	19-20
Detaching	20
OPERATION	
Controls	21
Starting & Stopping the Sweeper, Travel Direction, Brush Speed, Angling the Sweeper	
Intended Use	22
Before Operating Sweeper	22
Operation.....	22
Operating Tips	23
Brush Pattern Adjustment.....	24
Adjusting Spring Chain Assembly.....	24-25
Adjusting Transport Chain	25
Storage.....	25-26
Lift & Tie Down Points	26
Transporting.....	26
LUBRICATION	
Lubrication	27
PTO Drivelines.....	27-28
Lubricating Gearbox	28
MAINTENANCE	
Routine Maintenance & Break-In Period	29
Reversing Sweeping Direction	30-31
Drive Chain Conditioning.....	31
Adjusting Drive Chain	32
Aligning Sprockets.....	33
Leveling	34
Replacing Brush Sections	35-36
TROUBLESHOOTING	37-38
SPECIFICATIONS	
Sweeper Specifications	39
Bolt Torque Specifications	40
PARTS / WARRANTY	41

**THIS PAGE
IS INTENTIONALLY
BLANK**

PREFACE

GENERAL COMMENTS

Congratulations on the purchase of your new product! This product was carefully designed and manufactured to give you many years of dependable service. Only minor maintenance (such as cleaning and lubricating) is required to keep it in top working condition. Be sure to observe all maintenance procedures and safety precautions in this manual and on any safety decals located on the product and on any equipment on which the attachment is mounted.

This manual has been designed to help you do a better, safer job. Read this manual carefully and become familiar with its contents.

WARNING! Never let anyone operate this unit without reading the "Safety Precautions" and "Operating Instructions" sections of this manual.



Always choose hard, level ground to park the vehicle on and set the brake so the unit cannot roll.

Unless noted otherwise, right and left sides are determined from the operator's control position when facing forward.

NOTE: The illustrations and data used in this manual were current (according to the information available to us) at the time of printing, however, we reserve the right to redesign and change the attachment as may be necessary without notification.

BEFORE OPERATION

The primary responsibility for safety with this equipment falls to the operator. Make sure the equipment is operated only by trained individuals that have read and understand this manual. If there is any portion of this manual or function you do not understand, contact your local authorized dealer or the manufacturer to obtain further assistance. Keep this manual available for reference. Provide the manual to any new owners and/or operators.

SAFETY ALERT SYMBOL



This is the "Safety Alert Symbol" used by this industry. This symbol is used to warn of possible injury. Be sure to read all warnings carefully. They are included for your safety and for the safety of others working with you.

SERVICE

Use only manufacturer replacement parts. Substitute parts may not meet the required standards.

Record the model and serial number of your unit on the cover of this manual. The parts department needs this information to insure that you receive the correct parts.

SOUND AND VIBRATION

Sound pressure levels and vibration data for this attachment are influenced by many different parameters: some items are listed below (not inclusive):

- prime mover type, age, condition, with or without cab enclosure and configuration
- operator training, behavior, stress level
- job site organization, working material condition, environment

Based on the uncertainty of the prime mover, operator, and job site, it is not possible to get precise machine and operator sound pressure levels or vibration levels for this attachment.

NOTE: A list of all Paladin Patents can be found at <http://www.paladinattachments.com/patents.asp>.

SAFETY STATEMENTS



THIS SYMBOL BY ITSELF OR WITH A WARNING WORD THROUGHOUT THIS MANUAL IS USED TO CALL YOUR ATTENTION TO INSTRUCTIONS INVOLVING YOUR PERSONAL SAFETY OR THE SAFETY OF OTHERS. FAILURE TO FOLLOW THESE INSTRUCTIONS CAN RESULT IN INJURY OR DEATH.



DANGER

THIS SIGNAL WORD INDICATES A HAZARDOUS SITUATION WHICH, IF NOT AVOIDED, WILL RESULT IN DEATH OR SERIOUS INJURY.



WARNING

THIS SIGNAL WORD INDICATES A HAZARDOUS SITUATION WHICH, IF NOT AVOIDED, COULD RESULT IN DEATH OR SERIOUS INJURY.



CAUTION

THIS SIGNAL WORD INDICATES A HAZARDOUS SITUATION WHICH, IF NOT AVOIDED, COULD RESULT IN MINOR OR MODERATE INJURY.

NOTICE

NOTICE IS USED TO ADDRESS PRACTICES NOT RELATED TO PHYSICAL INJURY.

GENERAL SAFETY PRECAUTIONS

WARNING!



READ MANUAL PRIOR TO INSTALLATION

Improper installation, operation, or maintenance of this equipment could result in serious injury or death. Operators and maintenance personnel should read this manual, as well as all manuals related to this equipment and the prime mover thoroughly before beginning installation, operation, or maintenance.

FOLLOW ALL SAFETY INSTRUCTIONS IN THIS MANUAL AND THE PRIME MOVER'S MANUAL(S).



READ AND UNDERSTAND ALL SAFETY STATEMENTS

Read all safety decals and safety statements in all manuals prior to operating or working on this equipment. Know and obey all OSHA regulations, local laws, and other professional guidelines for your operation. Know and follow good work practices when assembling, maintaining, repairing, mounting, removing, or operating this equipment.



KNOW YOUR EQUIPMENT

Know your equipment's capabilities, dimensions, and operations before operating. Visually inspect your equipment before you start, and never operate equipment that is not in proper working order with all safety devices intact. Check all hardware to ensure it is tight. Make certain that all locking pins, latches, and connection devices are properly installed and secured. Remove and replace any damaged, fatigued, or excessively worn parts. Make certain all safety decals are in place and are legible. Keep decals clean, and replace them if they become worn or hard to read.

GENERAL SAFETY PRECAUTIONS

WARNING!



PROTECT AGAINST FLYING DEBRIS

Always wear proper safety glasses, goggles, or a face shield when driving pins in or out, or when any operation causes dust, flying debris, or any other hazardous material.

WARNING!



LOWER OR SUPPORT RAISED EQUIPMENT

Do not work under raised booms without supporting them. Do not use support material made of concrete blocks, logs, buckets, barrels, or any other material that could suddenly collapse or shift positions. Make sure support material is solid, not decayed, warped, twisted, or tapered. Lower booms to ground level or on blocks. Lower booms and attachments to the ground before leaving the cab or operator's station.


WARNING!



USE CARE WITH HYDRAULIC FLUID PRESSURE

Hydraulic fluid under pressure can penetrate the skin and cause serious injury or death. Hydraulic leaks under pressure may not be visible. Before connecting or disconnecting hydraulic hoses, read your prime mover's operator's manual for detailed instructions on connecting and disconnecting hydraulic hoses or fittings.

- Keep unprotected body parts, such as face, eyes, and arms as far away as possible from a suspected leak. Flesh injected with hydraulic fluid may develop gangrene or other permanent disabilities.
- If injured by injected fluid, see a doctor at once. If your doctor is not familiar with this type of injury, ask him to research it immediately to determine proper treatment.
- Wear safety glasses, protective clothing, and use a piece of cardboard or wood when searching for hydraulic leaks. **DO NOT USE YOUR HANDS!** SEE ILLUSTRATION.



GENERAL SAFETY PRECAUTIONS

WARNING!



DO NOT MODIFY MACHINE OR ATTACHMENTS

Modifications may weaken the integrity of the attachment and may impair the function, safety, life, and performance of the attachment. When making repairs, use only the manufacturer's genuine parts, following authorized instructions. Other parts may be substandard in fit and quality. Never modify any ROPS (Roll Over Protective Structure) or FOPS (Falling Object Protective Structure) equipment or device. Any modifications must be authorized in writing by the manufacturer.

WARNING!



SAFELY MAINTAIN AND REPAIR EQUIPMENT

- Do not wear loose clothing or any accessories that can catch in moving parts. If you have long hair, cover or secure it so that it does not become entangled in the equipment.
- Work on a level surface in a well-lit area.
- Use properly grounded electrical outlets and tools.
- Use the correct tools for the job at hand. Make sure they are in good condition for the task required.
- Wear the protective equipment specified by the tool manufacturer.



SAFELY OPERATE EQUIPMENT

Do not operate equipment until you are completely trained by a qualified operator in how to use the controls, know its capabilities, dimensions, and all safety requirements. See your machine's manual for these instructions.

- Keep all step plates, grab bars, pedals, and controls free of dirt, grease, debris, and oil.
- Never allow anyone to be around the equipment when it is operating.
- Do not allow riders on the attachment or the prime mover.
- Do not operate the equipment from anywhere other than the correct operator's position.
- Never leave equipment unattended with the engine running, or with this attachment in a raised position.
- Do not alter or remove any safety feature from the prime mover or this attachment.
- Know your work site safety rules as well as traffic rules and flow. When in doubt on any safety issue, contact your supervisor or safety coordinator for an explanation.

WARNING!



CALIFORNIA PROPOSITION 65 WARNING

This product may contain a chemical known to the state of California to cause cancer, or birth defects or other reproductive harm. www.P65Warnings.ca.gov

EQUIPMENT SAFETY PRECAUTIONS

WARNING!



KNOW WHERE UTILITIES ARE

Observe overhead electrical and other utility lines. Be sure equipment will clear them. When digging, call your local utilities for location of buried utility lines, gas, water, and sewer, as well as any other hazard you may encounter.

WARNING!



EXPOSURE TO RESPIRABLE CRYSTALLINE SILICA DUST ALONG WITH OTHER HAZARDOUS DUSTS MAY CAUSE SERIOUS OR FATAL RESPIRATORY DISEASE.

It is recommended to use dust suppression, dust collection and if necessary personal protective equipment during the operation of any attachment that may cause high levels of dust.

WARNING!



REMOVE PAINT BEFORE WELDING OR HEATING

Hazardous fumes/dust can be generated when paint is heated by welding, soldering or using a torch. Do all work outside or in a well ventilated area and dispose of paint and solvent properly. Remove paint before welding or heating.

When sanding or grinding paint, avoid breathing the dust. Wear an approved respirator. If you use solvent or paint stripper, remove stripper with soap and water before welding. Remove solvent or paint stripper containers and other flammable material from area. Allow fumes to disperse at least 15 minutes before welding or heating.

WARNING!



END OF LIFE DISPOSAL

At the completion of the useful life of the unit, drain all fluids and dismantle by separating the different materials (rubber, steel, plastic, etc.). Follow all federal, state and local regulations for recycling and disposal of the fluid and components.



OPERATING THE SWEEPER

- Do not exceed the lifting capacity of your prime mover.
- Operate only from the operator's station.
- When traveling on rough terrain, reduce speed to avoid "bouncing" the sweeper. Loss of steering can result.
- When operating on slopes, drive up and down, not across. Avoid steep hillside operation, which could cause the prime mover to overturn.
- Reduce speed when driving over rough terrain, on a slope, or turning, to avoid overturning the vehicle.
- An operator must not use drugs or alcohol, which can change his or her alertness or coordination. An operator taking prescription or over-the-counter drugs should seek medical advice on whether or not he or she can safely operate equipment.
- Before exiting the prime mover, lower the attachment to the ground, disengage PTO, apply the brakes, turn off the prime mover's engine and remove the key.
- Never lift the lowest portion of the attachment plate higher than 5' above the ground.
- Do not lock the auxiliary hydraulics of your prime mover in the "ON" position.

EQUIPMENT SAFETY PRECAUTIONS



TRANSPORTING THE SWEEPER

- Disengage PTO before transporting.
- Travel only with the attachment in a safe transport position to prevent uncontrolled movement. Drive slowly over rough ground and on slopes.
- When transporting on a trailer: Secure attachment at recommended tie down locations using tie down accessories that are capable of maintaining attachment stability.
- When driving on public roads use safety lights, reflectors, Slow Moving Vehicle signs etc., to prevent accidents. Check local government regulations that may affect you.
- Do not drive close to ditches, excavations, etc., cave in could result.
- Do not smoke when refueling the prime mover. Allow room in the fuel tank for expansion. Wipe up any spilled fuel. Secure cap tightly when done.



MAINTAINING THE SWEEPER


- Before performing maintenance, lower the attachment to the ground, disengage the PTO, apply the brakes, turn off the engine and remove the key.
- Be sure all rotation has stopped before approaching the sweeper.
- Disengage the PTO shaft before making any adjustments or repairs.
- Never perform any work on the attachment unless you are authorized and qualified to do so. Always read the operator service manuals before any repair is made. After completing maintenance or repair, check for correct functioning of the attachment. If not functioning properly, always tag "DO NOT OPERATE" until all problems are corrected.
- Worn, damaged, or illegible safety decals must be replaced. New safety decals can be ordered from Paladin.
- Never make hydraulic repairs while the system is under pressure. Serious personal injury or death could result.
- Never work under a raised attachment unless PTO has been disengaged and sweeper is securely blocked.

DECALS

DECAL PLACEMENT

GENERAL INFORMATION

The diagram on this page shows the location of the decals used on your attachment. The decals are identified by their part numbers, with reductions of the actual decals located on the following page. Use this information to order replacements for lost or damaged decals. Be sure to read all decals before operating the attachment. They contain information you need to know for both safety and product longevity.



IMPORTANT: Keep all safety decals clean and legible. Replace all missing, illegible, or damaged safety decals. When replacing parts with safety decals attached, the safety decals must also be replaced. Safety decals are available, free of charge, from your local dealer or Paladin.

REPLACING SAFETY DECALS: Clean the area of application with nonflammable solvent, then wash the same area with soap and water. Allow the surface to fully dry. Remove the backing from the safety decal, exposing the adhesive surface. Apply the safety decal to the position shown in the diagram above and smooth out any bubbles.


DECALS



50-0726 WARNING!
FLYING OBJECTS & ENTANGLEMENT




41043 WARNING!
HAZARDOUS DUST




50-0722 WARNING!
MISUSE HAZARD




50-0115 DANGER!
ROTATING DRIVELINE



50-0721 WARNING! CRUSH POINT



50-0147 FREQUENCY OF LUBE



50-0236 GEARBOX, CHECK OIL



50-0010-1 DANGER! ROTATING DRIVELINE
(LOCATED ON DRIVELINES)

NOTE: CONTACT YOUR LOCAL DEALER FOR MODEL NUMBER AND LOGO DECALS

INSTALLATION

RMRM sweepers are designed to attach to SAE Category I or Category II 3-point hitches. To attach this sweeper to a Category II hitch, you must order Category II hitch pins.

This sweeper has been assembled so it sweeps while traveling forward. It can, however, sweep while moving in reverse. See “Reversing Sweeping Direction” to sweep while driving in reverse.

DRAW BAR STYLE & INSTALLATION

Before installing onto your tractor check drawbar style and position. If your tractor is equipped with a clevis hitch (hammer-strap) style of drawbar it must be removed before installation. (See Figure #1) If your tractor is equipped with an offset style drawbar, the offset must be in the down position before installation. (See Figure #2)

FIGURE #1






FIGURE #2



INSTALLATION

1. Install hitch pins into the mounting frame while placing the chain supports on the inside of the mounting frame (bend towards the center) and secure in place with the hardware supplied with the hitch pins. See Figure #1
2. Connect a 39-link chain to each chain support using the two double link clevis pins provided. See Figure #1.


FIGURE #1



INSTALLATION


3. Install both top link chain brackets to the tractor top link with the existing pins from the tractor. See Figure #2

FIGURE #2



4. Position the mounting assembly behind the tractor with the swing plate toward the rear.
5. Lower the tractor 3-point hitch arms.
6. Install the mounting assembly hitch pins onto the tractor 3-point hitch arms and secure with klik pins provided. See Figure #1
7. Connect the tractor top link to the mounting assembly. Secure with existing pin. See Figure #3


FIGURE #3



8. Adjust 39-link chains, which are attached to the mounting assembly to the top link chain brackets installed in step #3. See Figure #2
 - a. Raise hitch arms until center of bolt holes on the mounting assembly swing plate are 16" (406mm) above the ground. See Figure #4
 - b. Mark the link in each chain that will maintain this measurement.
 - c. Raise hitch arms slightly and place the pre-marked links in the top link chain keyhole.
 - d. Lower the mounting assembly and verify the center of bolt holes on the mounting assembly swing plate is 16" (406mm) above the ground.

INSTALLATION

FIGURE #4




NOTE: For wet, heavy and/or deep snow, adjust support chains so the mounting assembly remains 20"-22" (508-559mm) off the ground when the unit is lowered.

NOTICE! Avoid equipment damage. Positioning the sweeper too close to the ground, less than 16" (406mm) can result in damage to the sweeper hood and gearbox.

9. Position the brush head assembly behind the mounting assembly.
10. Aligning the slots in the swing plate and brush head pivot plate loosely install the carriage bolts and hardware provided. Make sure the top edges of the plates are parallel with each other and then tighten hardware securing the mounting assembly to the brush head. See Figure #5

FIGURE #5




NOTE: Make sure the top edges of the plates are parallel with each other. This becomes very important when adjusting the sweeper after installation.

INSTALLATION

11. Install the spring-chain assembly. The spring-chain assembly should come assembled. If it is not, attach the springs to the 26-link chains in an alternating pattern: chain, spring, chain, spring, chain. See Figure #6
 - a. Attach the middle chain to the brush frame upright so that there are 7 links between slots.
 - b. Connect the end chains to the slots in the chain holder on the mounting assembly.


FIGURE #6



12. Connect the 36-link transport chain from the center slot on the brush frame upright, to the remaining slot in the chain holder on the mounting assembly. See Figure #6
13. Install the CV (constant velocity) PTO driveline shaft. See Figure #7
 - a. Connect the hex end of the CV shaft to the hex shaft on the brush head assembly.
 - b. Attach the round end of the CV shaft to the gearbox output shaft.
 - c. Tighten set screws and jam nuts.
14. Install the 6-Spline PTO driveline shaft. See Figure #7
 - a. Connect the round end of the PTO shaft to the gearbox input shaft. Tighten the set screw and jam nut.
 - b. Connect the 6-spline end of the PTO shaft to the tractor PTO. (Pull back on the driveline yoke collar and align the splines of the yoke with the PTO shaft. Push yoke onto the PTO shaft releasing the locking collar.) **NOTE: Push and pull the driveline back and forth until locked in place.**

INSTALLATION

FIGURE #7



WARNING! The locking collar must slide freely and the locking balls seated in the groove on the tractor PTO shaft before operating. A driveline not attached correctly could come loose from the tractor resulting in personal injury and damage to the attachment.

NOTE: It may be necessary to shorten the telescoping shaft. The shaft must slip freely as the brush head assembly is raised and lowered. Raise and lower the sweeper slowly to check that the telescoping shaft is the proper length. See "Power (PTO) Shaft Adjustment".

NOTICE! Avoid driveline damage. Check the length of the telescoping members to ensure the driveline will not bottom out or separate when turning and/or going over rough terrain.

NOTICE! The PTO is customized for your specific application. If the PTO shaft is too long, severe PTO and gearbox damage is possible. **DO NOT FORCE THE PTO TO FIT.** Warranty is void if the correct PTO is not installed. There should never be less than .50" of overlap within the PTO.

WARNING! Do not use a PTO adapter to attach your sweeper to a non-matching tractor PTO. Serious personal injury and/or equipment failure can result. Consult an authorized dealer for assistance if the sweeper PTO does not match the tractor PTO.


15. Adjust the top link so the swing frame is perpendicular to the ground.
16. Install the manual or hydraulic angle kit. See angle kit installation instructions.
17. See instructions provided with your optional kits.

INSTALLATION

MANUAL ANGLE INSTALLATION

1. Slide the inner link (with one hole) into the outer link.
2. Place assembly on large pins welded to the sweeper. The inner link goes on the brush head frame pin. See Figure #8

FIGURE #8




3. Secure with hair pins.
4. Swing the sweeper to the desired angle. Make sure to align a set of holes in the links.
5. Insert a lock pin in the aligned holes.

HYDRAULIC ANGLE INSTALLATION

1. If not already installed, attach fittings to the cylinder. See Figure #9


FIGURE #9



INSTALLATION

2. Install the cylinder with the barrel end on the mounting frame pin and the rod end on the brush head frame pin. Secure with cotter pins. See Figure #10

FIGURE #10



3. Connect a hose to each fitting on the cylinder.
4. Attach adapter fittings to the hose ends.
5. Connect the adapter fittings to the auxiliary hydraulic system of your prime mover.

NOTE: Additional hydraulic equipment, such as quick couplers and valves are customer supplied.

POWER (PTO) SHAFT ADJUSTMENT

Confirm the minimum and maximum working lengths of the driveshaft. The telescoping tubes must overlap by at least 1/3 of their length while in use. The (PTO) drive assembly may need to be shortened to fit up to your tractor correctly and to prevent the drive assembly from “bottoming out” and causing extensive damage to the tractor PTO drive assembly.




The shaft assembly is shortest when the shaft is straight inline with the attachment. There should be a minimum of .50" (13mm) of free travel before the shaft is fully retracted. To check:

1. Lower the attachment until the shaft is parallel to the ground and is straight inline with the attachment gearbox.
2. Check to see if there is a minimum of .50" free travel.

If there is not at least .50" (13mm) of free travel DO NOT OPERATE ATTACHMENT.

NOTICE! If the drive shaft “bottoms out” before it is straight inline with the attachment, stop and call your nearest dealer or the attachment manufacturer before operating.

INSTALLATION



CAUTION! Failure to have the required distance of clearance will damage the power take off (PTO) of your tractor. The minimum and maximum length of the PTO must be checked whenever this attachment is used on a different tractor.



DETACHING

NOTICE! Hoses for the hydraulic angle kit must be removed before the quick attach is disengaged. Pulling the sweeper with the hoses could result in damage to the prime mover or sweeper.

1. Before exiting the prime mover, lower the attachment to the ground, disengage PTO, apply the brakes, turn off the prime mover's engine and remove the key.
2. Follow prime mover operator's manual to relieve pressure in the hydraulic lines (if so equipped).
3. Lock storage legs in lowered position.
4. Disconnect driveline from tractor PTO shaft and support with storage chain.
5. Disconnect hydraulic angle hoses from the rear remote hydraulics (if so equipped).
6. Install caps onto the hydraulic hoses to prevent contaminants from entering the hydraulic system. Store hoses off of the ground to help prevent damage (if so equipped).
7. Follow your prime mover operator's manual for detaching (removing) an attachment.

OPERATION CONTROLS

STARTING AND STOPPING THE SWEEPER

Starting The Sweeper

1. Start the prime mover at idle and raise the brush.
2. Engage the PTO at idle to start brush rotation.
3. Lower sweeper to the ground and increase engine RPM to desired sweeping speed.

Stopping The Sweeper

1. Decrease engine RPM to idle.
2. Raise brush off the ground.
3. Disengage PTO at idle.

TRAVEL DIRECTION

Travel should be in the forward direction and brush rotation always away from the operator.

BRUSH SPEED

To increase brush speed, increase engine RPM. Use the LOWEST speed needed to complete the job at hand. In general, half throttle provides the necessary engine speed. Vary brush, engine and travel speeds to match sweeping conditions.

ANGLING THE SWEEPER

Use the angle feature to control the direction debris exits the sweeper. Angling the brush head the same direction as the wind also helps reduce the amount of material that blows onto the operator and the surface swept.

Manual Angle Kit with Tube Links

1. Remove the lock pin from links.
2. Position the brush head at the desired angle, aligning holes in the inner and outer link.
3. Insert and close the lock pin.

Optional Hydraulic Angle Kit

1. Start the prime mover.
2. Engage auxiliary hydraulic controls.
3. Position the brush head at the desired angle.

OPERATION

INTENDED USE

This sweeper is designed solely for use in construction cleanup, road maintenance and similar operations. Use in any other way is considered contrary to intended use. Compliance with and strict adherence to operation, service and repair conditions, as specified by the manufacturer, are essential elements of intended use.

BEFORE OPERATING SWEEPER:

- Learn sweeper and prime mover controls in an off-road location.
- Run prime mover and sweeper at low idle.
- Before exiting the prime mover, lower the attachment to the ground, disengage PTO, apply the brakes, turn off the prime mover's engine and remove the key.
- Only operate the sweeper from the prime mover operator's station. Only operate controls while the engine is running. Protective glasses must be worn while you operate prime mover and sweeper.

OPERATION

Before operating: level the sweeper, set the angle, and adjust the brush pattern according to the instructions in this manual.

Carry the sweeper low to the ground so the operator has good visibility and stability. Avoid any sudden movements.

Avoid excessive downward pressure on the brush sections to prevent excessive wear. A 2" - 4" wide pattern is sufficient for most applications. Verify the top edges of the mounting assembly and brush head plates are parallel to prevent an uneven wear pattern. Adjust if necessary and tighten hardware. To adjust pattern see "Brush Pattern Adjustment".

Observe wind direction. Sweeping with the wind makes sweeping more effective and helps keep debris off the operator.

WARNING! AVOID SERIOUS INJURY. Check for objects that could harm the operator or others if thrown by the sweeper. Remove items before sweeping.



The terms *swing* and *angle* are used interchangeably.

Model M24 sweepers are powered from the PTO shaft at 540 RPM maximum.

1. Start the prime mover at idle and raise the brush.
2. Start brush rotation by engaging the PTO at idle.
3. Lower sweeper to the ground and increase prime mover engine RPM to the desired sweeping speed for your application.

NOTICE! Do not run the engine at speeds which make the PTO run faster than the recommended speed marked on the prime mover's tachometer.

4. Travel forward at 5 MPH (8 kph) or less.

NOTICE! When approaching obstacles, like utility poles or fire hydrants, slow engine and travel speed to avoid hitting these hazards.

OPERATION

OPERATING TIPS

Vary brush, engine and travel speeds to match sweeping conditions.

NOTICE! Do not ram into piles. Use a dozer blade for this type of job.

LARGE AREAS

When sweeping a large area, such as a parking lot, make a path down the middle and sweep to both sides. This reduces the amount of debris that the sweeper must sweep to one side.

SNOW

Fast brush speeds and slow travel speeds are needed to sweep snow effectively. Start at $\frac{3}{4}$ throttle and the lowest gear of the prime mover. For wet and/or deep snow, increase to almost full throttle. This helps keep snow from packing up inside the brush hood.

NOTICE: For best sweeping results, we recommend that the swing assembly mounting holes be 12" (305mm) above the ground. Failure to maintain this distance allows for swept material to be carried over the brush and back onto the swept area.

- In deep snow you may need to make multiple passes to get down to a clean surface.
- Always sweep with the wind at your back.

DIRT & GRAVEL

To keep dust at a minimum, plan sweeping for days when it is overcast and humid or after it has rained.

Low brush speeds and moderate travel speeds work best for cleaning debris from hard surfaces. Brush speeds that are too fast tend to raise dust.

To sweep gravel, use just enough brush speed to "roll" the gravel, not throw it.

HEAVY DEBRIS

- Travel slowly - 2 to 3 MPH (3-5 kph).
- Sweep a path less than the full width of the sweeper.
- Increase engine speed if debris becomes very heavy.

THATCH

Low brush speeds and low prime mover speeds do the best thatching job.

To prevent the brush from pulling itself into the ground, adjust the spring chain assembly so the bristle tips barely touch the grass.

If the brush pulls into the grass and stalls while sweeping, use the lift to raise the brush. Do not increase throttle to override a stall out.

Use a combination of brush speed and ground speed that rolls up a neat windrow.

To keep thatch from blowing back onto a swept area, sweep with the wind at your back or in the direction the brush is angled.


OPERATION

BRUSH PATTERN ADJUSTMENT

A properly adjusted brush offers the best sweeper performance. To check brush pattern:

1. Move the sweeper to a dusty, flat surface.
2. Set the prime mover's parking brake and leave the engine running.
3. Start the sweeper at a slow speed; then, lower it so bristle tips touch the ground. Run the sweeper in a stationary position for 10-30 seconds.
4. Raise the sweeper and back away; switch off the sweeper and engine and remove the key. The brush pattern left in the dust should be 2"-4" (51-102mm) wide, running the length of the brush. See Figure #1
5. Adjust the brush pattern as necessary. See **ADJUSTING SPRING CHAIN ASSEMBLY**


FIGURE #1



ADJUSTING SPRING CHAIN ASSEMBLY

The spring chain assembly sets the brush pattern by restricting up and down movement of the brush head assembly. See Figure #2

FIGURE #2



To adjust the brush pattern:

1. Lower the sweeper to the ground.
2. Raise the brush head assembly with the lift system you have.

OPERATION

3. Increase or decrease the number of links in the spring chain assembly between the drive assembly upright and the brush head upright. See Figure #2
 - Increase the number of links to lower the brush head.
 - Decrease the number of links to raise the brush head.
4. Adjust the transport chain.

ADJUSTING TRANSPORT CHAIN

The transport chain supports the weight of the brush head assembly during transport between work sites and during adjustment of the spring chain assembly. When sweeping, the transport chain should have one or two links of slack. See Figure #2

To adjust the transport chain for moving between sites:

1. Raise the sweeper.
2. Tighten the transport chain.
3. Lower the sweeper so the transport chain supports the weight of the sweeper.

STORAGE

The following storage procedure will help you to keep your product in top condition. It will also help you get off to a good start the next time your attachment is needed. We therefore strongly recommend that you take the extra time to follow these procedures whenever your unit will not be used for an extended period of time.

IMPORTANT: When detaching your unit for short or long term storage be sure to follow the Detaching Instruction in the Installation Section of this manual.

NOTICE: *Do not store the sweeper with weight on the brush. Weight will deform the bristles, destroying the sweeping effectiveness. To avoid this problem, place the sweeper on blocks or use storage legs.*

Do not store polypropylene brushes in direct sunlight. The material can deteriorate and crumble before the bristles are worn out. Keep polypropylene brush material away from intense heat or flame.

- Clean the unit thoroughly, removing all snow, dirt and grease.
- Inspect for visible signs of wear, breakage or damage. Order any parts required and make the necessary repairs to avoid delays upon removal from storage.
- Tighten loose nuts, capscrews, bolts and hydraulic connections (if so equipped).
- Coat exposed portions of the cylinder rods with grease (if so equipped).
- Lubricate grease fittings.
- Seal hydraulic system from contaminants and secure all hydraulic hoses off the ground to help prevent damage (if so equipped).
- Replace decals that are damaged or in unreadable condition.
- Store unit in a dry and protected place. Leaving the unit outside will materially shorten its life.

Additional Precautions for Long Term Storage:

- Touch up all unpainted surfaces with paint to avoid rust.

OPERATION

REMOVAL FROM STORAGE:

- Wash unit and replace any damage and/or missing parts.
- Lubricate grease fittings.
- Check hydraulic hoses for damage and replace as necessary (if so equipped).

LIFT POINTS

Lifting points are identified by lifting decals where required. Lifting at other points is unsafe and can damage attachment. Do not attach lifting accessories around cylinders or in any way that may damage hoses or hydraulic components.

- Attach lifting accessories to unit at recommended lifting points.
- Bring lifting accessories together to a central lifting point.
- Lift gradually, maintaining the equilibrium of the unit.

WARNING! Use lifting accessories (chains, slings, ropes, shackles and etc.) that are capable of supporting the size and weight of your attachment. Secure all lifting accessories in such a way to prevent unintended disengagement. Failure to do so could result in the attachment falling and causing serious personal injury or death.



TIE DOWN POINTS

Tie down points are identified by tie down decals where required. Securing to trailer at other points is unsafe and can damage attachment. Do not attach tie down accessories around cylinders or in any way that may damage hoses or hydraulic components.

- Attach tie down accessories to unit as recommended.
- Check unit stability before transporting.

WARNING! Verify that all tie down accessories (chains, slings, ropes, shackles and etc.) are capable of maintaining attachment stability during transporting and are attached in such a way to prevent unintended disengagement or shifting of the unit. Failure to do so could result in serious personal injury or death.



TRANSPORTING

Follow all local government regulations that may apply along with recommended tie down points and any equipment safety precautions at the front of this manual when transporting your attachment.

LUBRICATION

LUBRICATION

All parts provided with grease fittings should be lubricated as indicated. If any grease fittings are missing, replace them immediately. Clean all fittings thoroughly before using grease gun.




Lubricate daily or every 8 hours of operation, whichever comes first, with SAE Multi-Purpose Lubricant or an equivalent SAE Multi-Purpose type grease.



Lubricate every 20 hours of operation with NL-GI2 grease or an equivalent.




Lubricate weekly or every 40 hours of operation, whichever comes first, with SAE Multi-Purpose Lubricant or an equivalent SAE Multi-Purpose type grease.



PTO DRIVELINES

- Lubricate the outboard hub and the PTO every (8) eight hours.
- Grease PTO driveline inner tube before putting attachment into operation and every (20) twenty hours thereafter.




IMPORTANT: Avoid excessive greasing. Dirt collects on exposed grease and greatly increases wear. After greasing, wipe off excessive grease from fittings.

LUBRICATION

*** When used in winter the outer tube must be greased to prevent it freezing solid!**

**GREASE INSIDE OF OUTER
TELESCOPING TUBE (EVERY
20 HOURS)**



- It is recommended to use NL-GI2 grease or equivalent for all grease points.

LUBRICATING GEARBOX

After the first 100 operating hours, drain the oil and flush the gearbox with an approved, nonflammable, nontoxic solvent. Refill with oil.

Following the first oil change, change oil after every 2,500 operating hours or 6 months, whichever comes first.


Hubcity gearboxes

To check gearbox lubricant level, remove the vent plug located in the hinged area of gearbox shield. If lubricant seeps out the hole, the gearbox is full.

To add lubricant:

1. Remove the vent and fill plugs.
2. Add multi-purpose 220-weight gear lubricant into the fill hole until lubricant runs out the vent hole.
3. Replace both plugs.

An empty gearbox takes 19oz of lubricant.



MAINTENANCE

GENERAL INFORMATION

Regular maintenance is the key to long equipment life and safe operation. Maintenance requirements have been reduced to the absolute minimum. However, it is very important that these maintenance functions be performed as described below.

Procedure	Daily (Every 8 Hours)	Twice a Week (Every 20 Hours)	Weekly (Every 40 Hours)	Quarterly (Every 3 Months)
Check hardware for tightness. (See Bolt Torque Specifications)	✓			
Check universal joints for wear. Tighten set screws and jam nuts.	✓			
Check brush pattern. (See Brush Pattern Adjustments)	✓			
Check hydraulic system for leaks and tighten as necessary. Check for damage and replace as needed.	✓			
Check prime mover hydraulic system for adequate oil levels.	✓			
Check for missing or damaged safety decals and replace as necessary.	✓			
Lubricate all PTO grease fittings with high quality grease.	✓			
Lubricate all brush head grease fittings with high quality grease.			✓	
Check sprocket alignment. (See Aligning Sprockets)			✓	
Check drive chain for adjustment. (See Adjusting Drive Chain)			✓	
Inspect wires & apply silicon spray to connectors. (if equipped)			✓	
Lubricate PTO driveline.		✓		
Lubricate & check drive chain for frozen links. (See Drive Chain Conditioning)				✓
Change oil in gearbox.				✓

BREAK-IN PERIOD

Change oil in gearbox after the first 100 hrs or 30 days of operating and then quarterly.

WARNING!



Escaping hydraulic / diesel fluid under pressure can penetrate the skin causing serious injury. Fluid escaping from a very small hole can be almost invisible. Use a piece of cardboard or wood, rather than hands to search for suspected leaks. Keep unprotected body parts, such as face, eyes, and arms as far away as possible from a suspected leak. Flesh injected with hydraulic fluid may develop gangrene or other permanent disabilities. If injured by injected fluid, see a doctor at once.


MAINTENANCE

REVERSING SWEEPING DIRECTION

All RMRM sweepers are shipped with the gearbox set to sweep forward while driving forward. To reverse the gearbox rotation to sweep while backing up:


1. Remove PTO drivelines and the shield from the gearbox. Mark gearbox shafts for identification purposes (we used white tape). See Figure #1.

FIGURE #1




2. Remove the gearbox from the mounting assembly. See Figure #2

FIGURE #2



3. Remove the vent plug and drain plug & switch locations (reinstall plugs in the opposite holes). Tighten both plugs securely. See Figure #3


FIGURE #3



MAINTENANCE

4. Flip gearbox over and reinstall. The vent plug must be on top of the gearbox. See Figure #4

FIGURE #4




5. Reinstall the gearbox shield. See Figure #5.

WARNING! AVOID SERIOUS INJURY OR DEATH. Do not operate the sweeper without all shields installed.



FIGURE #5



6. Install PTO drivelines on gearbox shafts. Tighten set screws and jam nuts.
7. Check gearbox lubricant level. Fill if necessary.
8. Operate the unit at a low rpm while observing for excessive vibrations or other problems. Correct before using the unit.

DRIVE CHAIN CONDITIONING


1. Remove drive chain.
 - a. Remove rear drive shield.
 - b. Loosen flange bearing carriage bolts and slide bearing forward.
 - c. Remove chain from back sprocket, locate master link and remove.
2. Soak chain in penetrating oil.
3. Bend back and forth.
4. Lubricate chain.
5. Reinstall chain by reversing the above procedure. (Replace if necessary.)
6. Adjust drive chain. See **ADJUSTING DRIVE CHAIN**

MAINTENANCE

ADJUSTING DRIVE CHAIN


1. Remove the front drive shield. See Figure #1

FIGURE #1



2. Loosen but do not remove bolts securing bearing assemblies on both sides of the brush head assembly. See Figure #2

FIGURE #2



3. Slide the brush away from mounting assembly until there is .38" to .50" (10-13mm) of play in the chain.

NOTICE! Avoid drive chain and sprocket damage. The drive chain must have .38" to .50" (12-13mm) of play. Over-tightening wears the chain and sprockets prematurely.

4. Tighten bolts on each bearing assembly.
5. Reinstall the front drive shield.

WARNING! AVOID SERIOUS INJURY OR DEATH. Do not operate the sweeper without all shields in place.




MAINTENANCE

ALIGNING SPROCKETS

Keep sprockets aligned to prevent chain derailment and reduce wear on the drive chain and sprockets.


1. Remove front and rear drive shield from the fixed chain guard. See Figure #1

FIGURE #1



2. For each sprocket, measure from inside the frame to the center of the sprocket. See Figure #2

FIGURE #2



3. Compare measurements.
 - If they are the same, sprockets are aligned.
 - If they are different, loosen the set screw on the small sprocket. Adjust it until it is the same distance as the large one. Tighten the set screw.
4. Reinstall drive shields.

WARNING! AVOID SERIOUS INJURY OR DEATH. Do not operate the sweeper without all shields in place.



MAINTENANCE

LEVELING

Level the sweeper for even brush wear and effective use.

1. Move the unit to a dusty, paved surface.
2. Lower the brush head assembly so the bristle tips are 2" (51mm) above the ground.
3. Engage the parking brake and shut down the prime mover. Unfasten safety restraints and exit prime mover.
4. Swing the brush head assembly straight ahead.
5. At each end of the brush head, measure from the center of the core shaft to the ground. See Figure #1
 - If measurements are the same, go to step 6.
 - If measurements are not equal, make sure the top edges of the mounting assembly and brush head plates are parallel. Adjust, if necessary, and tighten the hardware. Then, lengthen or shorten the adjustable hitch arm. Repeat until measurements are equal.
6. Swing the sweeper to the right. Take measurements as in step 5. Swing sweeper to the left and measure again.
 - If all measurements are equal, the sweeper is level.
 - If measurements are not equal, level the mounting assembly with the top link. Follow instructions below, repeat until the sweeper is level.
 - a. If measurements resemble Figure #2, lengthen the top link.
 - b. If measurements resemble Figure #3, shorten the top link.

FIGURE #1




FIGURE #2





FIGURE #3



NOTE: Make sure the PTO driveline does not hit the mounting frame when the unit is raised. Reset lift limits if necessary.

7. Verify brush pattern. See Brush Pattern Adjustment

MAINTENANCE

REPLACING BRUSH SECTIONS

1. Remove the front bolt from inside the right side of the brush frame. This allows you to remove the drive shield and right mounting bracket. See Figure #1
2. Remove the middle bolt from the right side of the brush frame.
3. Remove the 2 bolts from the left side of the brush frame. See Figure #2

FIGURE #1






FIGURE #2



4. Remove the drive chain from the core sprocket.
5. Pull the brush out of the brush frame.
6. Stand the brush on end and rest it on blocks.
7. Unbolt & remove the flange bearing. See Figure #3
8. Remove retainer plates.

FIGURE #3



9. Remove old sections from the core.
10. Install new sections.
 - a. Number the tubes on the core as 1, 2 and 3. See Figure #5
 - b. Slide the first section onto the core with the drive pins on both sides of tube 1. Make sure that drive pins angle up. See Figure #5

MAINTENANCE

Note: Drive pin direction can be difficult to determine. Inspect your sections to determine up and down directions. See Figure #4

FIGURE #4




FIGURE #5





FIGURE #6



NOTICE! When using a wire brush kit or a mixed poly/wire brush kit, place a poly section first and last on the core to prevent damage to the hood, driveline and frame.

- c. Place the second section on the core with drive pins on both sides of tube 2. Be sure drive pins angle down. See Figure #6
- d. Slide the third section onto the core with drive pins around tube 3. Be sure the drive pins angle up.
- e. Slide sections on until the core is full, making sure to alternate the tubes used and the direction of the drive pins.
11. Place the retainer plates on the brush and reinstall the capscrews.
12. Position the brush in front of the brush hood.
13. Slide the brush into the left side of the brush frame. Reinstall the hardware but do not tighten completely.
14. Slide the right side of the brush into the brush frame. Position the drive chain on the core sprocket and reinstall the middle bolt but do not tighten.
15. Install the front drive shield and mounting bracket and reinstall the front bolt.
16. Tighten the hardware on the left side.
17. Align the sprockets and adjust the drive chain. See **ALIGNING SPROCKETS** and **ADJUSTING DRIVE CHAIN**

Worn Section Standard				Reference Information	
SECTION OD, NEW	RING ID	SECTION OD, WORN	EXPOSED BRISTLE, WORN	BRISTLE LENGTH	EXPOSED BRISTLE, NEW
24"	6.38"	17"	3.8"	8.50"	7.5"


TROUBLESHOOTING

PROBLEM	POSSIBLE CAUSE	POSSIBLE SOLUTION
BRUSH ROTATES WRONG DIRECTION	Incorrect gearbox or gearbox flipped.	Contact Paladin service department.
BRUSH HEAD ASSEMBLY “BOUNCES” WHEN SWEEPING	Brush pattern needs adjustment.	See Brush Pattern Adjustment.
	Ground speed too fast and/or brush speed too slow.	Find correct combination of ground and brush speeds.
	Core is bent.	Replace core.
BRUSH WEARS UNEVENLY	Brush head assembly is not level.	Level brush head. See Leveling.
BRUSH WEARS VERY QUICKLY	Brush pattern not adjusted correctly.	See Brush Pattern Adjustment.
	Brush speeds too high.	Reduce brush speeds.
DRIVE CHAIN FALLS OFF REPEATEDLY	Core not riding on sprocket.	Align core.
	Not enough tension on chain.	Slide core forward.
GEARBOX DOES NOT TURN	Broken shaft or gear.	Do not open a gearbox still under warranty; contact Paladin for replacement parts.
OIL LEAKING FROM PINION HOUSING, CAPS, CAPSCREWS OR PIPE PLUGS	Loose hardware.	Tighten hardware to specification using Loctite® if required. Replace gaskets if necessary.
HIGH INTERNAL OPERATING TEMPERATURE (ABOVE 200°F [93.33°C])	Damaged bearings.	Replace bearings.
	Oil level too low.	Add oil.
EXCESSIVE END PLAY IN SHAFTS (.005 INCHES [.13MM] OR MORE) WHEN COUPLINGS ARE REMOVED	Worn gearbox bearings.	Contact Paladin service department.
EXCESSIVE BACKLASH	Worn sprockets.	Adjust drive chain; replace sprockets, if necessary.
END AND/OR INBOARD YOKE EARS SPREAD	Drive shaft too long.	Adjust drive shaft length; replace parts if necessary.
	Axial forces too high - running above recommended RPM.	Clean and grease profile tubes; replace parts; replace both tubes, if necessary.

TROUBLESHOOTING

PROBLEM	POSSIBLE CAUSE	POSSIBLE SOLUTION
END YOKE EARS HAVE PRESSURE MARKS	Excessive bend angle when shaft rotates.	Avoid running brush in raised position; switch off tractor PTO during cornering or when lifting the brush head; replace parts if necessary.
END YOKE BEARING CAPS BLUED	Insufficient lubrication.	Follow lubrication instructions. Replace parts if necessary.
INBOARD YOKE EARS HAVE PRESSURE MARKS	Excessive bend angle when shaft rotates.	Avoid running brush in raised position; switch off tractor PTO during cornering or when lifting the brush head; replace parts if necessary.
	Drive shaft too long.	Adjust drive shaft length.
INBOARD YOKE BEARING CAPS BLUED	Insufficient lubrication.	Follow lubrication instructions; replace parts if necessary.
SHIELD TUBE DEFORMED AND SPLIT ON ONE SIDE	Shield tube too short or no overlap at all when drive shaft is extended.	Adjust shield tube length; replace parts if necessary.
SHIELD TUBES DAMAGED	Shields contact components on tractor and/or sweeper.	Allow more clearance; replace parts if necessary.
SHIELD CONE DESTROYED	Shield cone contacts components on tractor and/or sweeper.	Allow more clearance; replace parts if necessary.
TELESCOPING SECTIONS DISTORTED	Overload caused by high starting and peak torques or blocking.	Engage and disengage at idle; replace parts if necessary.

SPECIFICATIONS



**SPECIFICATIONS AND DESIGN ARE SUBJECT TO CHANGE
WITHOUT NOTICE AND WITHOUT LIABILITY THEREFOR.**

DESCRIPTION	4'	5'	6'
A. Overall Height	25.70"	25.70"	25.70"
B. Overall Width	52.90"	65.90"	78.90"
C. Overall Length*	34.20"	34.20"	34.20"
D. Sweeping Width	41.10"	54.10"	67.10"
E. Overall Length @ 30°*	47.30"	53.80"	60.30"
F. Overall Width @ 30°	60.40"	71.60"	82.90"
G. Sweeping Width @ 30°	35.60"	46.90"	58.90"
H. Center of Gravity - Horizontal*	13.50"	13.60"	14.20"
Weight (lbs)*	175#	209#	243#
Recommended Horsepower.....	15-30 HP		
Maximum PTO Speed	540 RPM		
*Specifications do not include mounting assembly.			

BOLT TORQUE SPECIFICATION

GENERAL TORQUE SPECIFICATION TABLES


Use the following charts when determining bolt torque specifications, when special torques are not given. Always use grade 5 or better when replacing bolts.

SAE BOLT TORQUE SPECIFICATIONS


Note: The following torque values are for use with extreme pressure lubricants, plating or hard washer applications. Increase torque 15% when using hardware that is unplated and either dry or lubricated with engine oil.

Bolt Size		SAE GRADE 5 TORQUE				SAE GRADE 8 TORQUE				Bolt head identification marks as per grade. NOTE: Manufacturing Marks Will Vary
		Ft-lbs		Newton-Meter		Ft-lbs		Newton-Meter		
Inches	mm	UNC	UNF	UNC	UNF	UNC	UNF	UNC	UNF	
1/4	6,35	8	9	11	12	10	13	14	18	
5/16	7,94	14	17	19	23	20	25	27	34	
3/8	9,53	30	36	41	49	38	46	52	62	
7/16	11,11	46	54	62	73	60	71	81	96	
1/2	12,70	68	82	92	111	94	112	127	152	
9/16	14,29	94	112	127	152	136	163	184	221	
5/8	15,88	128	153	174	207	187	224	254	304	
3/4	19,05	230	275	312	373	323	395	438	536	
7/8	22,23	340	408	461	553	510	612	691	830	
1	25,40	493	592	668	803	765	918	1037	1245	
1-1/8	25,58	680	748	922	1014	1088	1224	1475	1660	
1-1/4	31,75	952	1054	1291	1429	1547	1700	2097	2305	
1-3/8	34,93	1241	1428	1683	1936	2023	2312	2743	3135	
1-1/2	38,10	1649	1870	2236	2535	2686	3026	3642	4103	


Grade 2



Grade 5






Grade 8



METRIC BOLT TORQUE SPECIFICATIONS

NOTE: The following torque values are for use with metric hardware that is unplated and either dry or lubricated with engine oil. Reduce torque 15% when using hardware that has extreme pressure lubricants, plating or hard washer applications.

Bolt head identification marks as per grade.		
		

Bolt Size	Grade No.	Pitch (mm)	Ft-lbs	Newton-Meter	Pitch (mm)	Ft-lbs	Newton-Meter
M6	5.6	1,0	3.6-5.8	4.9-7.9	-	-	-
	8.8		5.8-4	7.9-12.7		-	-
	10.9		7.2-10	9.8-13.6		-	-
M8	5.6	1,25	7.2-14	9.8-19	1,0	12-17	16.3-23
	8.8		17-22	23-29.8		19-27	25.7-36.6
	10.9		20-26	27.1-35.2		22-31	29.8-42
M10	5.6	1,5	20-25	27.1-33.9	1,25	20-29	27.1-39.3
	8.8		34-40	46.1-54.2		35-47	47.4-63.7
	10.9		38-46	51.5-62.3		40-52	54.2-70.5
M12	5.6	1,75	28-34	37.9-46.1	1,25	31-41	42-55.6
	8.8		51-59	69.1-79.9		56-68	75.9-92.1
	10.9		57-66	77.2-89.4		62-75	84-101.6
M14	5.6	2,0	49-56	66.4-75.9	1,5	52-64	70.5-86.7
	8.8		81-93	109.8-126		90-106	122-143.6
	10.9		96-109	130.1-147.7		107-124	145-168
M16	5.6	2,0	67-77	90.8-104.3	1,5	69-83	93.5-112.5
	8.8		116-130	157.2-176.2		120-138	162.6-187
	10.9		129-145	174.8-196.5		140-158	189.7-214.1
M18	5.6	2,0	88-100	119.2-136	1,5	100-117	136-158.5
	8.8		150-168	203.3-227.6		177-199	239.8-269.6
	10.9		175-194	237.1-262.9		202-231	273.7-313
M20	5.6	2,5	108-130	146.3-176.2	1,5	132-150	178.9-203.3
	8.8		186-205	252-277.8		206-242	279.1-327.9
	10.9		213-249	288.6-337.4		246-289	333.3-391.6

PARTS

In order to provide you with the most UP-TO-DATE part information, all parts for this attachment have been moved to our website at www.paladinattachments.com/Manuals. Please use these diagrams and parts lists to locate replacement parts.

When servicing your attachment, remember to use only original manufacturer replacement parts. Substitute parts may not meet the standards required for safe, dependable operation.

To facilitate parts ordering when contacting the factory, please have the product control number (PCN or C/N) or model and serial number of your product ready to ensure that you receive the correct parts for your specific attachment.

The product control number, model and serial number for your attachment should be recorded in the space provided on the cover of this manual. This information may be obtained from the serial number identification plate located on your attachment.

NOTE: Most daily and emergency parts orders (in stock) received by 10:30 A.M. (Eastern Standard Time) will be shipped UPS Ground the same day received. UPS Next Day orders must be received by 1:30 PM (Eastern Standard Time.)

SERVICE DEPARTMENT

(734) 996-9116

(800) 456-7100

For Fax and E-mail Orders

PLC_Sales@paladinattachments.com

(734) 996-9014

WARRANTY

In order to provide you with the most UP-TO-DATE Warranty information, Paladin Warranty Statement and Warranty Procedures along with Warranty Registration and Claim Forms have been moved to our website at www.paladinattachments.com.