



# PALADIN®

## OPERATOR'S HANDBOOK

### VIBRATORY ROLLER



SERIAL NUMBER: \_\_\_\_\_

Original  
Part Number: 75653-X  
Rev. 3

MODEL NUMBER: \_\_\_\_\_



+33 (0)2 54 52 40 00 | [www.dubuis.com](http://www.dubuis.com)

STANLEY Dubuis 17-19, rue Julee Berthonneau-BP 3406 41034 Blois Cadex, FRANCE

800-456-7100 | [www.paladinattachments.com](http://www.paladinattachments.com) 503 Gay Street, Delhi, IA 52223, United States of America Copyright ©

H182 9-22-21-5



# TABLE OF CONTENTS

<b>PREFACE .....</b>	3
<b>SAFETY PRECAUTIONS</b>	
SAFETY STATEMENTS .....	5
GENERAL SAFETY PRECAUTIONS.....	5-7
EQUIPMENT SAFETY PRECAUTIONS .....	8-9
<b>DECALS</b>	
DECAL PLACEMENT.....	10
DECALS .....	11-12
<b>INSTALLATION</b>	
GENERAL INFORMATION.....	13
NOMENCLATURE.....	13
ATTACHING .....	13
DETACHING.....	14
<b>OPERATION</b>	
INTENDED USE.....	15
GENERAL INFORMATION.....	15
OPERATING PROCEDURE.....	15
STORAGE .....	16
LIFT POINTS.....	16
TIE DOWN POINTS .....	17
TRANSPORTING .....	17
<b>MAINTENANCE AND SERVICE</b>	
GENERAL MAINTENANCE - EVERY 8 / 100 / 500 HOURS .....	18
CHANGING GEAR LUBE.....	19
DRUM REMOVAL.....	20
DRUM INSTALLATION.....	20
REPLACING VIBRATION ISOLATORS .....	21
REPLACING LEFT BEARINGS AND/OR HUBS.....	21-22
REPLACING RIGHT BEARINGS AND/OR HUBS .....	23-24
HYDRAULIC MOTOR REPLACEMENT.....	24
<b>TROUBLESHOOTING.....</b>	25
<b>SPECIFICATIONS</b>	
SPECIFICATIONS .....	26
BOLT TORQUE SPECIFICATIONS.....	27
<b>DECLARATION OF CONFORMITY</b>	

**THIS PAGE  
IS INTENTIONALLY  
BLANK**

# PREFACE

## GENERAL INFORMATION

This product was carefully designed and manufactured to give you many years of dependable service. Only minor maintenance (such as cleaning and lubricating) is required to keep it in top working condition. Be sure to observe all maintenance procedures and safety precautions in this manual and on any safety decals located on the product and on any equipment on which the attachment is mounted.

**WARNING!** **Never let anyone operate this unit without reading the "Safety Precautions" and "Operating Instructions" sections of this manual.**



**Always choose hard, level ground to park the vehicle on and set the brake so the unit cannot roll.**

Unless noted otherwise, right and left sides are determined from the operator's control position when facing the attachment.

**NOTE: The illustrations and data used in this manual were current (according to the information available to us) at the time of printing, however, we reserve the right to redesign and change the attachment as may be necessary without notification.**

## BEFORE OPERATION

The primary responsibility for safety with this equipment falls to the operator. Make sure the equipment is operated only by trained individuals that have read and understand this manual. If there is any portion of this manual or function you do not understand, contact your local authorized dealer or the manufacturer to obtain further assistance. Keep this manual available for reference. Provide the manual to any new owners and/or operator's

## SAFETY ALERT SYMBOL



This is the "Safety Alert Symbol" used by this industry. This symbol is used to warn of possible injury. Be sure to read all warnings carefully. They are included for your safety and for the safety of others working with you.

## SERVICE

Use only manufacturer replacement parts. Substitute parts may not meet the required standards.

Record the model and serial number of your unit on the cover of this manual. The parts department needs this information to insure that you receive the correct parts.

## SOUND AND VIBRATION

Sound pressure levels and vibration data for this attachment are influenced by many different parameters: some items are listed below (not inclusive):

- prime mover type, age, condition, with or without cab enclosure and configuration
- operator training, behavior, stress level
- job site organization, working material condition, environment

Based on the uncertainty of the prime move, operator, and job site, it is not possible to get precise machine and operator sound pressure levels or vibration levels for this attachment.

**NOTE: A list of all Paladin Patents can be found at <http://www.paladinattachments.com/patents.asp>.**

**THIS PAGE  
IS INTENTIONALLY  
BLANK**

# SAFETY STATEMENTS



THIS SYMBOL BY ITSELF OR WITH A WARNING WORD THROUGHOUT THIS MANUAL IS USED TO CALL YOUR ATTENTION TO INSTRUCTIONS INVOLVING YOUR PERSONAL SAFETY OR THE SAFETY OF OTHERS. FAILURE TO FOLLOW THESE INSTRUCTIONS CAN RESULT IN INJURY OR DEATH.



## DANGER

THIS SIGNAL WORD IS USED WHERE SERIOUS INJURY OR DEATH WILL RESULT IF THE INSTRUCTIONS ARE NOT FOLLOWED PROPERLY.



## WARNING

THIS SIGNAL WORD IS USED WHERE SERIOUS INJURY OR DEATH COULD RESULT IF THE INSTRUCTIONS ARE NOT FOLLOWED PROPERLY.



## CAUTION

THIS SIGNAL WORD IS USED WHERE MINOR INJURY COULD RESULT IF THE INSTRUCTIONS ARE NOT FOLLOWED PROPERLY.

## NOTICE

NOTICE INDICATES A PROPERTY DAMAGE MESSAGE.

## GENERAL SAFETY PRECAUTIONS

### WARNING!

#### READ MANUAL PRIOR TO INSTALLATION



Improper installation, operation, or maintenance of this equipment could result in serious injury or death. Operators and maintenance personnel should read this manual, as well as all manuals related to this equipment and the prime mover thoroughly before beginning installation, operation, or maintenance. **FOLLOW ALL SAFETY INSTRUCTIONS IN THIS MANUAL AND THE PRIME MOVER'S MANUAL(S).**



#### READ AND UNDERSTAND ALL SAFETY STATEMENTS

Read all safety decals and safety statements in all manuals prior to operating or working on this equipment. Know and obey all OSHA regulations, local laws, and other professional guidelines for your operation. Know and follow good work practices when assembling, maintaining, repairing, mounting, removing, or operating this equipment.



#### KNOW YOUR EQUIPMENT

Know your equipment's capabilities, dimensions, and operations before operating. Visually inspect your equipment before you start, and never operate equipment that is not in proper working order with all safety devices intact. Check all hardware to ensure it is tight. Make certain that all locking pins, latches, and connection devices are properly installed and secured. Remove and replace any damaged, fatigued, or excessively worn parts. Make certain all safety decals are in place and are legible. Keep decals clean, and replace them if they become worn or hard to read.

# GENERAL SAFETY PRECAUTIONS

## WARNING!



### PROTECT AGAINST FLYING DEBRIS

Always wear proper safety glasses, goggles, or a face shield when driving pins in or out, or when any operation causes dust, flying debris, or any other hazardous material.

## WARNING!



### LOWER OR SUPPORT RAISED EQUIPMENT

Do not work under raised booms without supporting them. Do not use support material made of concrete blocks, logs, buckets, barrels, or any other material that could suddenly collapse or shift positions. Make sure support material is solid, not decayed, warped, twisted, or tapered. Lower booms to ground level or on blocks. Lower booms and attachments to the ground before leaving the cab or operator's station.


## WARNING!



### USE CARE WITH HYDRAULIC FLUID PRESSURE

Hydraulic fluid under pressure can penetrate the skin and cause serious injury or death. Hydraulic leaks under pressure may not be visible. Before connecting or disconnecting hydraulic hoses, read your prime mover's operator's manual for detailed instructions on connecting and disconnecting hydraulic hoses or fittings.

- Keep unprotected body parts, such as face, eyes, and arms as far away as possible from a suspected leak. Flesh injected with hydraulic fluid may develop gangrene or other permanent disabilities.
- If injured by injected fluid, see a doctor at once. If your doctor is not familiar with this type of injury, ask him to research it immediately to determine proper treatment.
- Wear safety glasses, protective clothing, and use a piece of cardboard or wood when searching for hydraulic leaks. **DO NOT USE YOUR HANDS!**  
**SEE ILLUSTRATION.**



# GENERAL SAFETY PRECAUTIONS

## WARNING!



### DO NOT MODIFY MACHINE OR ATTACHMENTS

Modifications may weaken the integrity of the attachment and may impair the function, safety, life, and performance of the attachment. When making repairs, use only the manufacturer's genuine parts, following authorized instructions. Other parts may be substandard in fit and quality. Never modify any ROPS (Roll Over Protection Structure) or FOPS (Falling Object Protective Structure) equipment or device. Any modifications must be authorized in writing by the manufacturer.

## WARNING!



### SAFELY MAINTAIN AND REPAIR EQUIPMENT

- Do not wear loose clothing or any accessories that can catch in moving parts. If you have long hair, cover or secure it so that it does not become entangled in the equipment.
- Work on a level surface in a well-lit area.
- Use properly grounded electrical outlets and tools.
- Use the correct tools for the job at hand. Make sure they are in good condition for the task required.
- Wear the protective equipment specified by the tool manufacturer.



### SAFELY OPERATE EQUIPMENT

Do not operate equipment until you are completely trained by a qualified operator in how to use the controls, know its capabilities, dimensions, and all safety requirements. See your machine's manual for these instructions.

- Keep all step plates, grab bars, pedals, and controls free of dirt, grease, debris, and oil.
- Never allow anyone to be around the equipment when it is operating.
- Do not allow riders on the attachment or the prime mover.
- Do not operate the equipment from anywhere other than the correct operator's position.
- Never leave equipment unattended with the engine running, or with this attachment in a raised position.
- Do not alter or remove any safety feature from the prime mover or this attachment.
- Know your work site safety rules as well as traffic rules and flow. When in doubt on any safety issue, contact your supervisor or safety coordinator for an explanation.

# EQUIPMENT SAFETY PRECAUTIONS

## WARNING!



### KNOW WHERE UTILITIES ARE

Observe overhead electrical and other utility lines. Be sure equipment will clear them. When digging, call your local utilities for location of buried utility lines, gas, water, and sewer, as well as any other hazard you may encounter.

## WARNING!



### EXPOSURE TO RESPIRABLE CRYSTALLINE SILICA DUST ALONG WITH OTHER HAZARDOUS DUSTS MAY CAUSE SERIOUS OR FATAL RESPIRATORY DISEASE.

It is recommended to use dust suppression, dust collection and if necessary personal protective equipment during the operation of any attachment that may cause high levels of dust.

## WARNING!



### REMOVE PAINT BEFORE WELDING OR HEATING

Hazardous fumes/dust can be generated when paint is heated by welding, soldering or using a torch. Do all work outside or in a well ventilated area and dispose of paint and solvent properly. Remove paint before welding or heating.

When sanding or grinding paint, avoid breathing the dust. Wear an approved respirator. If you use solvent or paint stripper, remove stripper with soap and water before welding. Remove solvent or paint stripper containers and other flammable material from area. Allow fumes to disperse at least 15 minutes before welding or heating.

## WARNING!



### END OF LIFE DISPOSAL

At the completion of the useful life of the unit, drain all fluids and dismantle by separating the different materials (rubber, steel, plastic, etc.). Follow all federal, state and local regulations for recycling and disposal of the fluid and components.

## OPERATING THE VIBRATORY ROLLER

- Block off work area from bystanders, livestock, etc.
- Operate only from the operator's station.
- Do not lift loads in excess of the capacity of the prime mover.
- When operating on slopes, drive up and down, not across. Avoid steep hillside operation, which could cause the prime mover to overturn.
- Reduce speed when driving over rough terrain, on a slope, or turning, to avoid overturning the vehicle.
- An operator must not use drugs or alcohol, which can change his or her alertness or coordination. An operator taking prescription or over-the-counter drugs should seek medical advice on whether or not he or she can safely operate equipment.
- Before exiting the prime mover, lower the attachment to the ground, apply the parking brakes, turn off the prime mover's engine, and remove the key.

# EQUIPMENT SAFETY PRECAUTIONS



## TRANSPORTING THE VIBRATORY ROLLER

- Travel only with the attachment in a safe transport position to prevent uncontrolled movement. Drive slowly over rough ground and on slopes.
- When driving on public roads use safety lights, reflectors, Slow Moving Vehicle signs etc., to prevent accidents. Check local government regulations that may affect you.
- Do not drive close to ditches, excavations, etc., cave in could result.
- Do not smoke when refueling the prime mover. Allow room in the fuel tank for expansion. Wipe up any spilled fuel. Secure cap tightly when done.



## MAINTAINING THE VIBRATORY ROLLER

- Before performing maintenance, lower the attachment to the ground, apply the parking brakes, turn off the engine, and remove the key.
- Never perform any work on the attachment unless you are authorized and qualified to do so. Always read the operator service manual's before any repair is made. After completing maintenance or repair, check for correct functioning of the attachment. If not functioning properly, always tag "DO NOT OPERATE" until all problems are corrected.
- Worn, damaged, or illegible safety decals must be replaced. New safety decals can be ordered from Paladin free of charge.
- Never make hydraulic repairs while the system is under pressure. Serious personal injury or death could result.
- Never work under a raised attachment.

## DECALS


### DECAL PLACEMENT

#### GENERAL INFORMATION

The following diagrams show the location of all the decals used on your attachment. The decals are identified by their part numbers, with the reductions of the actual decals shown on the following pages. Use this information to order replacements for lost or damaged decals. Be sure you understand all decals before operating the attachment. They contain information you need to know for attachment safety. (See decal explanations on the following pages.)

**IMPORTANT:** Keep all safety decals clean and legible. Replace all missing, or damaged safety decals. When replacing parts with safety decals attached, the safety decals must also be replaced.

**REPLACING SAFETY DECALS:** Clean the area of application with a nonflammable solvent, then wash the same area with soap and water. Allow the surface to dry. Remove the backing from the safety decal, exposing the adhesive surface. Apply the safety decal to the position shown in the diagram, and smooth out any bubbles.



# DECALS



## ⚠ WARNING

### PINCH POINT HAZARD: (50-0834)

Keep a safe distance away when any portion of this machine is in motion. Failure to heed this warning could result in serious injury or death.




## ⚠ WARNING

### READ MANUALS: (50-0831)

Do NOT operate or service unless you have read and understand the instruction and safety information in the operator's handbook and all prime mover manuals.

### TO AVOID EQUIPMENT DAMAGE AND/OR PER-

**SONAL INJURY:** Do not operate this attachment on hi-flow hydraulic system. Maximum 25 GPM (94.64 lpm) on standard flow units.



## ⚠ WARNING

### HIGH PRESSURE FLUID HAZARD: (50-0833)

Escaping fluid under pressure can have sufficient force to penetrate skin causing serious personal injury. Fluid escaping from a very small hole can be almost invisible. Use a piece of cardboard or wood, rather than hands to search for suspected leaks.

Keep unprotected body parts, such as face, eyes, and arms as far away as possible from a suspected leak.

Flesh injected with hydraulic fluid may develop gangrene or other permanent disabilities.

If injured by injected fluid, see a doctor at once. If your doctor is not familiar with this type of injury, ask him to research it immediately to determine proper treatment.




## ⚠ WARNING

### REMOVE KEY: (41013)

Lower attachment to the ground, set the parking brake, shut off the engine and remove the key before performing maintenance or leaving the operator's station.

## DECALS



### LIFT POINT: (50-0769)

Identifies recommended lift point locations. Lifting unit at other points is unsafe and can damage attachment.

### ⚠ WARNING

#### CRUSH HAZARD: (50-0836)

Stay back a safe distance from hazard when any portion of this machine is in motion. Keep hands and feet away from under frame. Failure to heed this warning could result in serious injury or death.

# INSTALLATION


## GENERAL INFORMATION

The Paladin Vibratory Rollers were designed to be easy to use and maintain. They are operated by the prime mover's auxiliary hydraulics and mount to the toolbar/quick attach mechanism for easy operator hook-up.

**NOTICE: DO NOT operate the Vibratory Rollers on a Hi-Flow hydraulic system (25 GPM maximum flow). Damage to the hydraulic motor will occur.**

## NOMENCLATURE

The purpose of this diagram is to acquaint you with the various names of the vibratory roller components. This knowledge will be helpful when reading through this manual or when ordering service parts.



## ATTACHING

Install the vibratory roller by following your power unit operator's manual for proper installation of an attachment. Connect the power and return hoses to the auxiliary hydraulic couplers on the prime mover. **NOTICE: All hose routings should be checked for kinks or pinched hoses. Reroute if necessary.**

**WARNING!** To avoid serious personal injury, make sure the Vibratory Roller is securely latched to the attachment mechanism of your unit. Failure to do so could result in separation of the attachment from the unit.



# INSTALLATION

## DETACHING

On firm, level ground. Lower the lift arms against the frame and place the roller on the ground.

Move the control levers back and forth to relieve pressure in the line. Disconnect couplers.

**NOTE: Connect couplers together or install caps to prevent contaminants from entering the hydraulic system.**

Follow your power unit operator's manual for detaching (removing) an attachment.

**CAUTION! Block vibratory roller drum to prevent rolling when not attached to loader.**



**NOTE: Frequent lubrication of grease fittings with a multi-purpose grease will greatly increase the life of the product.**

**IMPORTANT: DISENGAGE THE AUXILIARY HYDRAULICS, STOP THE ENGINE, ENGAGE PARKING BRAKE AND REMOVE KEY BEFORE LEAVING THE OPERATOR'S STATION.**

# OPERATION

**INTENDED USE:** This unit is designed to compact sand, gravel, soils, crushed stone and other aggregates while traveling forward or in reverse. Use in any other way is considered contrary to the intended use.

## GENERAL INFORMATION

Performance of the roller varies greatly depending on the operator and how the attachment is used.

**WARNING!** **Read and understand the Safety Precautions section of this manual before beginning operation.**



**Operate the attachment only from the operator's station. Any other method could result in serious personal injury or death.**

**Do not allow bystanders in the area when operating.**

**Go up and down slopes, not across them. Keep the heavy end of the machine uphill.**

**Follow mandatory safety shutdown procedures before cleaning, adjusting, lubricating or servicing this attachment.**

## OPERATING PROCEDURE

1. Position the roller in the desired starting location and lower the attachment to the ground.
2. Lower the loader arms and roll the toolbar out until the top of the roller frame is parallel to the ground and the front tires of the loader are approximately 1-3 inches (2.54-7.62 cm) off the ground.
3. Engage the auxiliary hydraulics on the loader and slowly drive forward.
4. After you have reached the end of the pass, reverse the skid steer and drive slowly backwards to further pack the soil and cover any tire tracks.

**IMPORTANT: The drive circuit is bi-directional but, it is recommended that you reverse the auxiliary hydraulic flow when you reverse direction.**

**NOTICE: *DO NOT operate the Vibratory Roller on Hi-Flow hydraulic systems (25 GPM maximum). Damage to the hydraulic motor will occur.***

# OPERATION

## STORAGE

- Clean the unit thoroughly, removing all mud, dirt, and grease.
- Inspect for visible signs of wear, breakage, or damage. Order any parts required and make the necessary repairs to avoid delays upon removal from storage.
- Tighten loose nuts, capscrews and hydraulic connections.
- Lubricate grease fittings.
- Seal hydraulic system from contaminants and secure all hydraulic hoses off the ground to help prevent damage.
- Replace decals that are damaged or in unreadable condition.
- Store unit in a dry and protected place. Leaving the unit outside will materially shorten its live.

### Additional Precautions for Long Term Storage:


- Touch up all unpainted surfaces with paint to prevent rust.

## REMOVAL FROM STORAGE

- Remove cover.
- Wash unit and replace any damaged and/or missing parts.
- Lubricate grease fittings.
- Check hydraulic hoses for damage and replace as necessary.

## LIFT POINTS

Lifting points are identified by lifting decals where required. Lifting at other points is unsafe and can damage attachment. Do not attach lifting accessories around cylinders or in any way that may damage hoses or hydraulic components. See Diagram



- Attach lifting accessories to unit at recommended lifting points.
- Bring lifting accessories together to a central lifting point.
- Lift gradually, maintaining the equilibrium of the unit.

# OPERATION


**WARNING!** Use lifting accessories (chains, slings, ropes, shackles and etc.) that are capable of supporting the size and weight of your attachment. Secure all lifting accessories in such a way to prevent unintended disengagement. Failure to do so could result in the attachment falling and causing serious personal injury or death.

## TIE DOWN POINTS

Tie down points are identified by tie down decals where required. Securing to trailer at other points is unsafe and can damage attachment. Do not attach tie down accessories around cylinders or in any way that may damage hoses or hydraulic components. See Diagram

CHOCKS MAY BE REQUIRED  
TO OBTAIN UNIT STABILITY  
DURING TRANSPORTING

DO NOT ATTACH TIE DOWN  
ACCESSORIES OVER HOSES  
OR VALVE



- Attach tie down accessories to unit as recommended.
- Check unit stability before transporting.

**WARNING!** Verify that all tie down accessories (chains, slings, ropes, shackles and etc.) are capable of maintaining attachment stability during transporting and are attached in such a way to prevent unintended disengagement or shifting of the unit. Failure to do so could result in serious personal injury or death.

## TRANSPORTING

Follow all local government regulations that may apply along with recommended tie down points and any equipment safety precautions at the front of this handbook when transporting your attachment.

# MAINTENANCE AND SERVICE

## GENERAL INFORMATION

Regular maintenance is the key to long equipment life and safe operation. Maintenance requirements have been kept to a minimum. However it is important that these maintenance functions be performed as described.

**WARNING!** **Read the Safety Precautions section of this manual before performing any maintenance procedure.**



**Follow all mandatory safety shutdown procedures outlined in the prime mover operator's manual before adjusting, cleaning, lubricating or servicing this attachment.**

Procedure	Daily	EVERY 100 HOURS	EVERY 500 HOURS
Lubricate all grease fittings. (One fitting located on back of hitch frame).	✓		
Hardware - Check for tightness (see Bolt Torque Specifications)	✓		
Replace any missing bolts or nuts with approved replacement parts.	✓		
Hydraulic System - Check for leaks and tighten as necessary. Check for damage and replace as needed.	✓		
Decals - Check for missing or damaged safety decals and replace as necessary.	✓		
Inspect attachment for any worn parts or cracked welds. Repair as required.	✓		
Check oil level in roller shaft.		✓	
Change gear oil in drive circuit using 80-90 weight gear lube.			✓

**WARNING!** **Escaping hydraulic fluid under pressure can have sufficient force to penetrate the skin causing serious personal injury. Fluid escaping from a very small hole can be almost invisible. Use a piece of cardboard or wood rather than your hands to search for suspected leaks.**



**Keep unprotected body parts, such as face, eyes, and arms as far away as possible from a suspected leak. Flesh injected with hydraulic fluid may develop gangrene or other permanent disabilities.**

**If injured by injected fluid see a doctor at once. If your doctor is not familiar with this type of injury, ask him to research it immediately to determine proper treatment.**

# MAINTENANCE AND SERVICE

## CHECK OIL LEVEL IN ROLLER SHAFT

On all units except the 84" roller, remove 90° elbow with fittings in the cover plate. Oil level is sufficient if oil is up to the fill hole. (On 84" rollers ONLY, oil should be visible in the clear tube). If unit is level and oil is not visible, service is required.

**NOTE: The Vibratory Roller is a sealed unit. If oil is low, service is required.**

## TO CHANGE GEAR LUBE:

1. Raise the left (motor side) of the vibratory roller using a hoist and place a 6" (15.24 cm) square block under the drum and lower the roller onto the block.
2. **All units except 84"**: On the right side of the vibratory roller, place a container (to catch the oil) under the cover plate and remove cover plate, leaving all fittings in place.  
**84" Roller ONLY**: On the right side of the vibratory roller, place a container (to catch the oil) under the reservoir assembly. Remove the square plug. Drain oil and then remove the reservoir assembly. More oil will drain.
3. Once the oil has been completely drained from the roller shaft, remove the block from the left side of the vibratory roller.
4. **84" Roller ONLY**: Using a hoist, raise the right side of the vibratory roller approximately 60 degrees. Using pre-measured oil, fill the shaft. You will not use all of the oil.
5. Place the right side of the vibratory roller onto the 6" (15.24 cm) square block.
6. Clean the existing silicone from the cover plate or the reservoir assembly(84" roller) and reinstall using new adhesive sealant (100% Silicone Rubber). Check for leaks.
7. **All units except 84"**: Remove the breather plug from the cover plate and fill the roller shaft with the amount of 80-90 weight gear lube recommended for your attachment. (See Oil Requirements below.) Replace breather plug with breather pointing up.  
**84" Roller ONLY**: Remove the square plug and fill reservoir with remaining oil. Reinstall square plug.

## OIL REQUIREMENTS (APPROXIMATE)

36" (91.44 cm) Vibratory Roller	=	1.00 Quart (.95 liters)
48" (121.9 cm) Vibratory Roller	=	1.38 Quarts (1.31 liters)
66" (167.6 cm) Vibratory Roller	=	2.00 Quarts (1.89 liters)
73" (185.4 cm) Vibratory Roller	=	2.13 Quarts (2.02 liters)
84" (213.4 cm) Vibratory Roller	=	4.24 Quarts (4.02 liters)

## DRUM REMOVAL

**NOTE: Removal of the isolator bolts will allow the vibratory roller frame to fall. Make sure the frame is completely supported before removing.**


## MAINTENANCE AND SERVICE

**WARNING!** NEVER place hands or fingers between the frame and drum assemblies during installation or removal. Severe personal injury could occur.



1. Using a loader or hoist, position the unit with the drum on the ground and the frame completely supported on blocks. Remove the motor guard and the motor bolts. Place a container (to catch the oil from the roller shaft) under the motor and remove the motor from the drum assembly. See Figure #1

**FIGURE #1**



2. Remove the .50" isolator bolts securing the roller frame to the drum and isolators. Using the loader or hoist, lift the frame assembly off of the drum assembly and set aside. See Figure #1
3. Use a hoist to finish draining the oil from the roller shaft. Drum removal is complete

## DRUM INSTALLATION

1. Lift the roller frame over the top of the drum assembly and into position. Reinstall the .50" bolts and hard flat washers securing the frame to the drum. (Install using Loctite 271 or equivalent.)

**WARNING!** NEVER place hands or fingers between the frame and drum assemblies during installation or removal. Severe personal injury could occur.



2. Reinstall the hydraulic motor, gasket and motor guard using the existing hardware. (Install motor using Loctite 271 or equivalent.)
3. Fill the roller shaft with 80-90 weight gear lube by following the procedure listed in **TO CHANGE GEAR LUBE.**

# MAINTENANCE AND SERVICE

## REPLACING VIBRATION ISOLATORS (RUBBER MOUNTS)

**NOTE:** Removal of the isolator bolts will allow the vibratory roller frame to fall. Make sure the frame is completely supported before removing.

1. Remove the drum by following the procedure listed for **DRUM REMOVAL**.
2. Remove the .50" UNC deformed lock nuts securing the isolators to the left and right hubs and install new isolators. Torque nuts to 55 ft. lbs. (74.6 N·m)

**NOTICE:** *Do NOT remove the hubs from the roller shaft. Removing the hubs without first supporting the roller shaft will cause damage to the roller shaft seal sleeves.*

3. Install the drum by following the procedure listed for **DRUM INSTALLATION**.


## REPLACING LEFT BEARINGS AND/OR HUBS

1. Remove the drum by following the procedure listed for **DRUM REMOVAL**.
2. Remove the bearing spacer, lock washer and lock nut from the end of the roller shaft by first bending back the engaged tab on the lock washer.
3. Insert a clean .62" (1.57 cm) rod into the motor end of the roller shaft and support the shaft in its current position.

**NOTICE:** *Removing the hubs without first supporting the roller shaft will cause damage to the roller shaft seal sleeves.*

4. Remove the outer bearing hub mounting bolts and slide both bearing hubs out and over the end of the rod while keeping the roller shaft firmly supported.

**FIGURE #2**




**NOTICE:** *DO NOT LET THE ROLLER SHAFT DROP AND COME INTO CONTACT WITH THE DRUM OR HUB. SEAL SLEEVE DAMAGE COULD OCCUR.*

## MAINTENANCE AND SERVICE

**NOTICE:** *Shaft and bearing hubs are heavy. Be careful not to drop one on the other as denting may occur.*

5. Pull the inner bearing out of the outer bearing hub. Remove the oil seal and snap ring from the end of the left inner hub. Tilt the housing to allow each bearing cone to fall out. See Figure #3
6. The bearing cup will need to be removed and replaced using an industrial press. Install new bearing cones. See Figure #3
7. Reinstall the snap ring and press on the new oil seal. See Figure #3
8. Remove the bearing retainer from the outer hub and using an industrial press, remove and replace the outer bearing. See Figure #3
9. Reinstall the bearing retainer using the existing hardware. See Figure #3
10. Apply a small amount of oil or grease to the outer bearing hub. Using an industrial press, assemble the outer bearing hub to the inner bearing hub.
11. While maintaining support of the roller shaft, slide the hub assemblies over the .62" (1.57 cm) rod and install securely to the drum using the existing .75" capscrews removed in step #4.
12. Reinstall the bearing spacer, lock washer and lock nut onto the end of the roller shaft. Torque the nut to 15 ft. lbs. (20.34 N·m). Be sure to fully engage the tab on the lock washer into the slot on the shaft nut.
13. Install the drum by following the procedure listed for **DRUM INSTALLATION**.

**FIGURE #3**



# MAINTENANCE AND SERVICE

## REPLACING RIGHT BEARINGS AND/OR HUBS

1. Remove the drum by following the procedure listed for **DRUM REMOVAL**.
2. Remove the reservoir assembly on the 84" roller or the cover plate with fittings. See Figure #4
3. Insert a clean .75" (1.9 cm) rod into the end of the roller shaft and support the shaft in its current position. See Figure #4


**NOTICE:** *Removing the hubs without first supporting the roller shaft will cause damage to the roller shaft seal sleeves.*

4. Remove the outer bearing hub mounting bolts and slide both bearing hubs out and over the end of the rod while keeping the roller shaft firmly supported. See Figure #4

**NOTICE:** *Do not let the roller shaft drop and come into contact with the drum or hub. Seal sleeve damage could occur.*

**NOTICE:** *Shaft and bearing hubs are heavy. Be careful not to drop one on the other as denting may occur.*


**FIGURE #4**



5. Remove the oil seal and snap ring from the end of the right inner hub. See Figure #5
6. Replacing Right Inner Hub Bearings:
  - a. If your unit is equipped with a spherical bearing, remove bearing and replace with two #107605 bearings (84" roller uses two #111442 bearings) and one #107387 spacer using an industrial press. Install new bearings. See Figure #5
  - b. If your unit is equipped with the two roller bearings and spacer, remove bearings and spacer and replace using an industrial press. Install new bearings. See Figure #5
  - c. If your unit is equipped with two ball bearings (no spacer), replace the complete right side inner hub assembly #104805.
7. Reinstall the snap ring and press on the new oil seal. See Figure #5

## MAINTENANCE AND SERVICE

8. Remove the bearing retainer from the outer hub and using an industrial press, remove and replace the outer bearing. See Figure #5
9. Reinstall the bearing retainer using the existing hardware. See Figure #5
10. Apply a small amount of oil or grease to the outer bearing hub. Using an industrial press, assemble the outer bearing hub to the inner bearing hub.
12. While maintaining support of the roller shaft, slide the hub assemblies over the .75" (1.9 cm) rod and secure to the drum using the existing .75" capscrews removed in step #4.
13. Reinstall the cover plate
14. Install the drum by following the procedure listed for **DRUM INSTALLATION**.



### HYDRAULIC MOTOR REPLACEMENT

1. Place a block under the left side of the vibratory roller and disconnect the hydraulic couplers from the prime mover. Remove the motor guard and the motor bolts. Tag and disconnect the hydraulic hoses from the hydraulic motor. Note the hose routing for re-installation.

**NOTE: IT IS RECOMMENDED THAT THE MOTOR GASKET BE REPLACED AT THE SAME TIME AS THE HYDRAULIC MOTOR.**

**NOTE: THE UPDATED HYDRAULIC MOTOR HAS A CAST HOUSING INSTEAD OF ALUMINUM. IF UPDATING YOUR UNIT YOU MUST ALSO REPLACE THE 10MBO-8MJ ELBOW WITH A 12MBO-8MJ ELBOW PART #3316 (GOING TO HOSE #38343).**

2. Remove the motor and gasket from the drum assembly and replace with the new hydraulic motor and gasket. Reconnect the hydraulic hoses and fittings to the new motor.

**NOTE: FIELD REPLACEMENT OF THE INTERNAL MOTOR SEALS VOIDS WARRANTY.**



3. Check for leaks. Reinstall the motor bolts and the motor guard.
4. Check oil level in roller shaft and fill as needed with 80-90 weight gear lube.

## TROUBLESHOOTING

PROBLEM	POSSIBLE CAUSE	POSSIBLE SOLUTION
Insufficient compaction	Prime mover "down pressure" insufficient  Operating RPM too slow	Increase the "down pressure" by raising the front wheels off the ground (see Operation)  Increase RPM to half throttle
Does not vibrate	Hydraulic couplers malfunctioning  Hydraulic couplers not completely engaged  Hydraulic motor damaged  Relief Valve damaged  Roller shaft bearings damaged  Low oil supply	Replace  Check and tighten couplers  Replace motor  Replace Relief Valve  Replace  Check for oil leaks and service as required
Excessive noise and/or vibration	Isolator's worn  Operating RPM too slow  Hydraulic motor damaged	Replace Isolators  Increase RPM to half throttle  Replace
Oil leaking	Oil seals damaged  Relief Valve damaged  Hydraulic motor damaged  Bearings damaged  Broken or loose hydraulic lines or fittings	Replace  Replace  Replace  Replace (replace oil seals at the same time)  Check for leaks and repair or replace
Drum will not turn	Frame installed incorrectly  Bearings damaged  Binding between frame and drum.	Check frame for correct installation and all hardware intact.  Replace  Remove
Vibratory roller not tilting correctly	Guide retainer on hitch too loose or too tight	Add or remove shims from hitch

# SPECIFICATIONS

## VIBRATORY ROLLER



SPECIFICATION AND DESIGN ARE SUBJECT TO CHANGE WITHOUT NOTICE AND WITHOUT LIABILITY THEREFORE.

### SMOOTH VIBRATORY ROLLERS

	<b>VRS36</b>	<b>VRS48</b>	<b>VRS66</b>	<b>VRS73</b>	<b>VRS84</b>
A. Overall Width in.(mm)	42" (1067)	61" (1549)	72" (1829)	79" (2007)	90" (2286)
B. Drum Width in.(mm)	36" (914)	48" (1219)	66" (1676)	73" (1854)	84" (2134)
C. Overall Height in.(mm)	22" (559)	31" (787)	31" (787)	31" (787)	31" (787)
D. Overall Length in.(mm)	34" (864)	39" (991)	39" (991)	39" (991)	39" (991)
E. Drum Diameter in.(mm)	20" (509)	24" (610)	24" (610)	24" (610)	24" (610)
Operating Weight lbs (kg)	840 (381)	1680 (762)	2150 (975)	2300 (1043)	2530 (1148)
Dynamic Force lbs (kg)	2488 (1129)	5750 (2608)	7800 (3538)	8550 (3878)	9370 (4250)
Vibrating Speed vpm	2000	2600	2600	2600	2600
Vibrating Weight lbs (kg)	507 (230)	935 (424)	1190 (540)	1290 (585)	1440 (653)
Drum Oscillation/Tilt (degrees)	15°	15°	15°	15°	15°
Maximum Flow gpm (lpm)	6-9/10-14 (23-34/38-53)	25 (95)	25 (95)	25 (95)	25 (95)

### PADDED VIBRATORY ROLLERS

	<b>VRP48</b>	<b>VRP66</b>	<b>VRP73</b>	<b>VRP84</b>
A. Overall Width in.(mm)	61" (1549)	72" (1829)	79" (2007)	90" (2286)
B. Drum Width in.(mm)	48" (1219)	66" (1676)	73" (1854)	84" (2134)
C. Overall Height in.(mm)	31" (787)	31" (787)	31" (787)	31" (787)
D. Overall Length in.(mm)	39" (991)	39" (991)	39" (991)	39" (991)
E. Drum Diameter (Without Pads) in.(mm)	20" (508)	20" (508)	20" (508)	20" (508)
Operating Weight lbs (kg)	1630 (739)	2085 (946)	2230 (1012)	2455 (1114)
Dynamic Force lbs (kg)	5750 (2608)	7800 (3538)	8550 (3878)	9370 (4250)
Vibrating Speed vpm (Hz)	2600	2600	2600	2600
Vibrating Weight lbs (kg)	890 (404)	1130 (513)	1225 (556)	1370 (621)
Drum Oscillation/Tilt (degrees)	15°	15°	15°	15°
Maximum Flow gpm (lpm)	25 (95)	25 (95)	25 (95)	25 (95)

**NOTE: Specifications are based on 20 GPM (76 LPM) hydraulic flow wherever applicable.**

**NOTE: VRS48 and VRP48 can be center mounted or offset 12" (309mm) to the right.**

# BOLT TORQUE SPECIFICATIONS


## GENERAL TORQUE SPECIFICATION TABLES

Use the following charts when determining bolt torque specifications when special torques are not given. Always use grade 5 or better when replacing bolts.

## SAE BOLT TORQUE SPECIFICATIONS

**NOTE:** The following torque values are for use with extreme pressure lubricants, plating or hard washer applications Increase torque 15% when using hardware that is unplated and either dry or lubricated with engine oil.

Bolt Size		SAE GRADE 5 TORQUE				SAE GRADE 8 TORQUE				Bolt head identification marks as per grade. NOTE: Manufacturing Marks Will Vary
		Pounds Feet		Newton-Meters		Pounds Feet		Newton-Meters		
Inches	Millimeters	UNC	UNF	UNC	UNF	UNC	UNF	UNC	UNF	
1/4	6.35	8	9	11	12	10	13	14	18	GRADE 2
5/16	7.94	14	17	19	23	20	25	27	34	
3/8	9.53	30	36	41	49	38	46	52	62	
7/16	11.11	46	54	62	73	60	71	81	96	
1/2	12.70	68	82	92	111	94	112	127	152	
9/16	14.29	94	112	127	152	136	163	184	221	
5/8	15.88	128	153	174	207	187	224	254	304	
3/4	19.05	230	275	312	373	323	395	438	536	
7/8	22.23	340	408	461	553	510	612	691	830	
1	25.40	493	592	668	803	765	918	1037	1245	
1-1/8	25.58	680	748	922	1014	1088	1224	1475	1660	
1-1/4	31.75	952	1054	1291	1429	1547	1700	2097	2305	GRADE 5
1-3/8	34.93	1241	1428	1683	1936	2023	2312	2743	3135	
1-1/2	38.10	1649	1870	2236	2535	2686	3026	3642	4103	



## METRIC BOLT TORQUE SPECIFICATIONS

**NOTE:** The following torque values are for use with metric hardware that is unplated and either dry or lubricated with engine oil. Reduce torque 15% when using hardware that has extreme pressure lubricants, plating or hard washer applications.

Bolt head identification marks as per grade.							
5.6	8.8	10.9	12-17	19-27	22-31	27.1-39.3	47.4-63.7

Size of Bolt	Grade No.	Pitch (mm)	Pounds Feet	Newton-Meters	Pitch (mm)	Pounds Feet	Newton-Meters
M6	5.6	1.0	3.6-5.8	4.9-7.9	-	-	-
	8.8		5.8-4	7.9-12.7		-	-
	10.9		7.2-10	9.8-13.6		-	-
M8	5.6	1.25	7.2-14	9.8-19	1.0	12-17	16.3-23
	8.8		17-22	23-29.8		19-27	25.7-36.6
	10.9		20-26	27.1-35.2		22-31	29.8-42
M10	5.6	1.5	20-25	27.1-33.9	1.25	20-29	27.1-39.3
	8.8		34-40	46.1-54.2		35-47	47.4-63.7
	10.9		38-46	51.5-62.3		40-52	54.2-70.5
M12	5.6	1.75	28-34	37.9-46.1	1.25	31-41	42-55.6
	8.8		51-59	69.1-79.9		56-68	75.9-92.1
	10.9		57-66	77.2-89.4		62-75	84-101.6
M14	5.6	2.0	49-56	66.4-75.9	1.5	52-64	70.5-86.7
	8.8		81-93	109.8-126		90-106	122-143.6
	10.9		96-109	130.1-147.7		107-124	145-168
M16	5.6	2.0	67-77	90.8-104.3	1.5	69-83	93.5-112.5
	8.8		116-130	157.2-176.2		120-138	162.6-187
	10.9		129-145	174.8-196.5		140-158	189.7-214.1
M18	5.6	2.0	88-100	119.2-136	1.5	100-117	136-158.5
	8.8		150-168	203.3-227.6		177-199	239.8-269.6
	10.9		175-194	237.1-262.9		202-231	273.7-313
M20	5.6	2.5	108-130	146.3-176.2	1.5	132-150	178.9-203.3
	8.8		186-205	252-277.8		206-242	279.1-327.9
	10.9		213-249	288.6-337.4		246-289	333.3-391.6



**PALADIN**  
CONSTRUCTION GROUP



## EU DECLARATION OF CONFORMITY

*I, the undersigned, on behalf of:*

Manufacturer/Technical Document Holder

Paladin Construction Group  
2800 N. Zeeb Road  
Dexter, MI 48130 USA  
Phone: 734-996-9116  
Fax: 734-996-9014

*hereby declare that the following product:*

Description of Equipment:

**Hydraulically driven Vibrating Roller with smooth or padded drum  
for skid steer loader applications. Used for compacting sand,  
gravel, soils, crushed stone and other aggregates.**

Attachment Model:

**VRS36, VRS48, VRP48, VRS66, VRP66, VRS73, VRP73, VRS84,  
VRP84**

Serial Number:

Conforms to:  
2006/42/EC Machinery Directive  
EN ISO 474-1, EN ISO 500-1 EN ISO 982,  
EN ISO 12100-1, EN ISO 12100-2, EN ISO 13857  
EN ISO 14121-1, EN ISO 2860, EN ISO 2867  
EN ISO 3457

Certification method: **Self-certified, per Annex V of the Directive**

Name and address of the person in the Community authorized to compile the technical construction file:

GENESIS GmbH  
Alpenstrasse 71  
Memmingen, GERMANY D – 87700

At Delhi, Signature, Title, Date

Signature: \_\_\_\_\_

Title: \_\_\_\_\_

Date: \_\_\_\_\_



## UKCA DECLARATION OF CONFORMITY

The undersigned, representing the following manufacturer:

**Manufacturer:** Paladin Attachments  
2800 N Zeeb Rd.  
Dexter, MI 48130  
United States

Declares that the product(s)

**Product identification:**

Description: HYDRAULIC CABLES CUTTING TOOLS WITH 18V RECHARGEABLE BATTERY  
Model: BCP040GC - BCP045GC - BCP055GC - BCP065CC - BCP085G+  
Serial number: L-00001 à L-99999

Conforms to the UK Regulations:

The supply of Machinery (Safety) Regulations 2008, S.I. 2008/1597 (as amended)  
Electromagnetic Compatibility Regulations, 2016, S.I. 2016/1091 (as amended)  
The Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations 2012, S.I. 2012/3032 (as amended)

Designated Standards:

SI 2008/1597 NF EN ISO 15744 (December 2008)  
NF EN ISO 3744 (February 2012)  
NF EN ISO 20643 (September 2008)  
NF EN ISO 11201 (December 2010)  
NF EN 12096 (September 1997)

SI 2016/1091 EN 62233 (September 2013)  
EN 55014-1 (June 2017)  
EN 55014-2 (July 2015)  
EN 62311 (October 2008)

S.I. 2012/3032 NF EN IEC 63000 (December 2018)

The undersigned is responsible for compilation of the technical file and makes this declaration on behalf of DUBUIS.

Signature

Blois, July 28, 2021

Patrick VERVIER,

Engineering Manager